UBAPY60SS

Built-In Electric Oven
User Manual



ACKNOWLEDGMENT

Thank you for purchasing our product. We hope you enjoy using the many features and benefits it provides. Before using this product please study this entire Instruction Manual carefully. Keep this manual in a safe place for future reference. Ensure that other people using the product are familiar with these instructions as well.

WARNING

- When the oven is first switched on, it may give off an unpleasant smell. This is due to the bonding agent used for the insulating panels within the oven. This is completely normal, if it does occur, you merely have wait for the smell to clear before putting food into the oven.
- The appliance and its accessible parts become hot during use.
- Care should be taken to avoid touching heating elements.
- Children less than 8 years of age should be kept away unless continuously supervised.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
  Cleaning and user maintenance should not be done by children without supervision.

- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass of the oven. This can scratch the surface and may result in permanent damage to the glass.
- During use, the appliance becomes very hot. Care should be taken to avoid touching heating elements inside the oven.
- Do not allow children to go near the oven when it is operating, especially when the grill is on.
- Ensure that the appliance is switched off before replacing the oven lamp to avoid the possibility of electric shock.
- The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring specifications.
- During pyrolytic cleaning, accessible parts may become hotter than normal. Young children should be kept away.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by person responsible for their safety.

SAFETY HINTS

- Do not use the oven unless you are wearing something on your feet. Do not touch the oven with wet or damp hands or feet.
- Oven door should not be opened often during the cooking period.
- The appliance must be installed by an authorized technician and put into use. The producer is not responsible for any damage that might be caused by defective placement, and installation by unauthorized personnel.
- When the door or drawer of oven is open do not leave anything on it, you may unbalance your appliance or break the door.
- Some parts of appliance may hold heat for a long time; it is required to wait for it to cool down before touching any points that are exposed to the heat directly.
- If you will not use the appliance for a long time, it is advised to turn it off at the mains.
- If the supply cord is damaged,it must be replaced by the persons in order to avoid a hazard.
- Before cleaning,remove all the accessories and excess spillage in the oven.
- During the pyrolytic self-cleaning cycle, the appliance will get hotter than normal cooking function therefore keep children away from the appliance.

FITTING THE OVEN INTO THE KITCHEN UNIT

Fit the oven into the space provided in the kitchen unit; it may be fitted underneath a work top or into a tall housing unit. Fix the oven in position by screwing into place, using the two fixing holes in the frame. To locate the fixing holes,open the oven door and look inside.To allow adequate ventilation, follow the measurements and distances adhered to when fixing the oven.

IMPORTANT

If the oven is to work properly, the kitchen housing must be suitable. The panels of the kitchen unit that are next to the oven must be made of a heat resistant material. Ensure that the glues of units that are made of veneered wood can with stand temperatures of at least 120ºC. Plastics or glues that cannot withstand such temperatures will melt and deform the unit,once the oven has been fitted inside the units, electrical parts must be completely insulated.This is a legal safety requirement.All guards must be firmly fixed into place so that it is impossibl to remove them without using special tools. Remove the back of the kitchen unit to ensure an adequate current of air circulates around the oven

DECLARATION OF COMPLIANCE

When you have unpacked the oven, make sure that it has not been damaged in any way. If you have any doubts at all, do not use it: contact a professionally qualified person. Keep packing materials such as plastic bags, polystyrene, or nails out of the reach of children because these are dangerous to children.

PRODUCT DESCRIPTION



Symbol	Function description
	Oven Lamp: which enables the user to observe the progress of cooking without opening the door.
	Defrost: The circulation of air at room temperature enables quicker thawing of frozen food, (without the use of any heat). It's a gentle but quick way to speed up the defrosting time and thawing of ready-made dishes and cream filled produce etc.
	Convection: An element around the convection fan provides an additional source of heat for convection style cooking. In convenction mode the fan automatically comes on to improve air circulation within the oven and creates an even heat for cooking. The temperature can be set within the range of 50-240℃. The default temperature is 180℃.
	Radiant grilling: The inner grill element switches on and off to maintain temperature. Best results can be obtained from using the top shelf for small items and lower shelves for large items.The temperature can be set within the range of 50-240℃. The default temperature is 210℃.
	Fan grilling: The inside radiant element and top element are working with fan The temperature can be set within the range of 180-240℃. The default temperature is 210
Pyrolytic mode	Pyrolytic function:When the function set to prolytic mode, LED display "PYA". The default temperature is 450℃ . The timer can be set 1:30 or 2:00 hours.

OPERATION INSTRUCTIONS

1. Clock Setting

After connectiong the unit to the power, the symbols 00:00 will be visible on the display.

1> Press " ", the hour figures will flash.

2> Rotate " K2" to adjust the hour figures, (Time should be within 0--23).

3> Press " ", the minutes will flash.

4> Rotate "K2 " to adjust the minutes setting, (time should be within 0-59).

5> Press " " to finish the clock settings. ":" will flash, and the time will be illuminated.

Note: The clock is 24 hours. After connected to the mains power, the clock will untimed.

2. Function Setting

1> Rotate " K1 " to choose the cooking function you require .The related indicator will illuminated .

2> Rotate " K2 " to adjust the temperature.

3> Press " " to confirm the start of cooking. The corresponding icon for temperature"°C"will be on.

4> If step 2 is ignored, Press " " to confirm the start of cooking. and the default time is 9 hours, the default temperature will display on the LED.

NOTE:

1>The step quantities for the adjustment time of the coding switch are as follow:

0--0:30min: step 1 minute 0:30--9:00hour :step 5 minutes

2>The step quantities for the adjustment of temperature is 5°C, and the radiant grilling function is 30°C.

3>Rotate " K1" to adjust the cooking time when cooking begins. Then press " " to start cooking. If " " not pressed within 3 seconds,the oven will revert back to the previous time to continue cooking.

4>Rotate"K2 " to adjust the temperature when cooking begins.The related indicator will be illuminated. Then press" " to start cooking. If " " not pressed in 3seconds, the oven will revert back to the previous temperatrue to continue cooking.

3.Lamp Setting

1> Rotate"K1" to select the relevant function, then the corresponding icon will be on.

2> Press " " button to start cooking. Lamp icon" " * " : "will flash.

4.Inquiring function

During cooking process, you can use inquiring function, after 3 seconds return to the current working state.

1> During cooking mode, press " " button to see the current time.

2> If the clock was set, press " "button to ask for cooking time.

5. Child lock function

To Lock : press " " and " " simultaneously for 3 seconds, there will be a long "beeping" sound indicating the children-lock is on and the " " will be illuminated.

Lock quitting : press " " and " " simultaneously for 3 seconds, there will be a long "beeping" sound indicating the child-lock is released.

Note: During working mode, if you want to stop cooking,press stop button quickly. Do not need to long pressing on stop button,it is invalid.

6. Reminder Function:

The oven has 9 hours reminder, this function will help to remind you to start cooking in a certain time from1 minute to 9 hours. Only when oven in standby mode, the reminder can be set. Follow below to set the reminder:

1> Press reminder setting button " ";

2> Rotate " K2 " to set the hour time of reminder. (Time should be within 0--9).

3> Press reminder setting button " " again;

4> Rotate "K2 " to set minute time of reminder. (Time should be within 0--59).

5> Press " " to confirm setting. ":" will be flash and the indicator for reminder " " will light.The time counts down.

Note: The oven buzzer will sound for 10 times after the time back to the zero hour . " "symbol disappears on the screen to remind you to start cooking. You can cancel the reminder during setting by pressing the stop button; After the reminder has been set, you can cancel it by pressing stop button twice.

7. Start/Pause/Cancel Function

1> If the cooking time has been set, press " " to start cooking. If the cooking is paused, press " " to resume cooking.

2> During cooking process, press " " once to pause the cooking. Press " " twice to cancel the cooking.

8. Energy-Saving Function

1> During in waiting state and reminding state , press " " for three seconds, the LED display will go off and set to energy-saving mode.

2> If no operation in10 minutes under waiting state, the LED display will go off and go into energy-saving mode.

3> Under the energy-saving mode, press any key or rotate any encoder can quit the energy-saving mode.

9. Pyrolytic Function(only some models)

This function allows you to clean thoroughly the oven cavity.

1>Rotate "K1" to select the pyrolytic function. LED will display "PYA".

2>Press " " to confirm the cooking. And the default time is 2 hours, "PYA" will display on the LED.

3>Rotate "K1" to change the pyrolytic time. There have two levers time can be selected"1:30 or 2:00".

Note:A) When the oven door is not closed, press start button will be invalid, LED display "DOOR","PYA."

B)When the oven center temperature is highter than 200°C,Press cancel button can return to waiting state directly and the oven center temperature is highter than 300°C, press start botton, LED display "COOL".

C)When open the door in normal working condition, the relay for heater will stop working, LED display "DOOR", the buzzer will beep continuously until the door closed or press the cancel button.

D)When the pyrolytic function finished working and oven center temperature is lower than 300°C. LED display will go off.

E)Before activating the pyrolytic cleaning function, remove any excessive spillage and make sure that oven is empty. Do not leave anything inside it(e.g. pans, baking tray, dripping pan, slider bracket etc.) as this could heavily damage them.

10.Reservation function

1> To use the timer function must set the clock How fat "clock setting":

2> the appointment time, according clock set (1), (2), (3), (4) set in step.

3> in the case of setting the reservation time, the clock key, but rotation " K1 " setting function. The reservation flag display " ⌛ "Always, check the function icons Always, default temperature " ℃ " steady.

4> press the " ⏯ " button, 4 " 8 " display " 9:00 " small " 8 " shows the default temperature of the stalls;

5> turn " K1 " coding switch to set the cooking time, 4" 8 "to set the time, the default temperature and the temperature icon lit; rotary coding switch "K2" is set to the cooking temperature.

6> press the " ⏯ " button to complete the appointment of cooking, to return to the clock display state; if the reservation flag " ⌛ "Always, function icon is not displayed, you can press the " " key to query the appointment, three seconds and returned the clock display state.

7> appointment to (such as clock for 8:00, set an appointment start time of 10:00, the the menu working hours for one hour, when the clock is 10:00 hours automatically start cooking at 11:00 when cooking end), tweet sound automatically begin cooking appointment flag " ⌛ "goes out, display the relevant cooking signage in accordance with the normal work.

Note:

A) Set the before "Appointment cooking program", you must first set the clock, otherwise not be able to set up an appointment cooking.

B) you can skip to step 5, the temperature is in accordance with the stall the default time 9:00, and the default.

C) furnace lights, thaw ,meat probe can not make an appointment.

D) appointment time you press the Cancel key flash menu significantly appointment time and temperature "℃" logo, the reservation menu icon Always, press the Cancel key back the clock state, or re-press the start key back to reservation status.

E) It is not available when the reservation status set reminders to remind state appointment can not be set.

11. Note

1>The oven lamp will be on for all functions.(except pyrolytic function)

2> Once the cooking programme has been set and the" ⏯ " button is not pressed within 5 minutes, the current time will be displayed or turn back to waiting state. The setting program will be invalid.

3>The buzzer sounds when effectively pressed, if not effectively pressed there will be no response.

4> The buzzer will sound five times to remind you when cooking has finished.

ACCESSORIES

Wire shelves : For grill .dishes, cake pan with items for roasting and grilling.



Grill pan and trivet: To be used for grilling and for collecting fat/spillage and meat juices.



To ensure the oven shelves operate safely, correct placement of the shelves between the side rails is imperative. This will ensure that during careful removal of the shelf or tray, hot food items should not slide out.



BULB REPLACEMENT

The bulb in the light is a special bulb, and has high temperature resistance (240V~25W). for replacement and proceed as follows:

1>. Isolate the appliance from the mains supply by switching the circuit breaker at the units mains outlet

2>.Unscrew the covering glass and replace the bulb with a new one of the same type.

3>.Screw the covering glass back in place.



SECURING THE OVEN TO THE CABINET

1. Fit oven into the cabinet recess.
2. Open the oven door.
3. Secure the oven to the kitchen cabint with two distance holders "A" which fit the holes in the oven frame and fit the two wood screws "B".



CONNECTION OF THE OVEN



INSTALLATION



Remark :

1. Only plus deviations are admissible for all dimension.
2. The power switch or socket that supplies the appliance should not be located in the installation housing. It should be located in an adjacent cabinet or above the worktop.

NOTE: The number of a accessories included depends on the particular appliance purchased.

CLEANING AND MAINTENANCE

For the sake of a good appearance and reliability, keep the unit clean. The modern design of the unit facilitates maintenance to a minimum. The parts of the unit which come into contact with food have to be cleaned regularly.

- Before any maintenance and cleaning, disconnect the power.
- Set all controls in the OFF position.
- Wait until the inside of the unit is not hot but only slightly warm- cleaning is easier than when warm.
- Clean the surface of the unit with a damp cloth, soft brush or fine sponge and then wipe dry. In case of heavy soiling, use hot water with non- abrasive cleaning product.
- For cleaning the glass of the oven door,do not use abrasive cleaners or sharp metal scrapers, these can scratch the surface or lead to the glass being damaged.
- Never leave acidic substances (lemon juice, vinegar) on stainless steel parts.
- Do not use a high pressure cleaner for cleaning the unit. The baking pans may be washed in mild detergent.
- A steam cleaner is not to be used.

This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment(WEEE).

By ensuring this product is disposed correctly, you will help prevent potential negative consequences for the environment and human health,which could otherwise be caused by inappropriate waste handling of this product. The symbol on the product indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste dispoasl.For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

USEFUL CONTACTS

SPARES & SERVICE

Myappliances

Phone: 0344 800 1128

Email: uksupport@apelson.co.uk

Web: www.myspareparts.co.uk