



Double Oven:KC272DTSS

Overheat Cut Out Thermostat			
Old Style (manual reset with capillary)	Top Oven	Part Number	33311013
	Bottom Oven	Part Number	33311013
New Style (self resetting "klixon" type)	Top Oven	Part Number	33308027
	Bottom Oven	Part Number	36154001


Version:02

Date:2014-08-13

Product reference code: 41KC272DTSS

KC272DTSS Exploded drawing

UPPER DOOR ASSY KC272DTXUDR



LOWER DOOR ASSY KC272DTXLDR

01	new design and modify some wrong codes	Paul	2013. 10. 18
Index	Modify description	Modified by	Date

See note on lead page regarding cut out thermostat.

No.	Part code	Part name	Quantity
1	33315002	rear fan assembly	1
2	33305016	connection box	1
3	32307016	power cord	1
4	33039015	side rack panel	2
5	33140011	side rack	2
6	33302002	lamp assembly	2
7	33311013	290 °C cut-out thermostat	2
8	33004010	fixing bracket for cut-out thermostat	2
9	33001037	back catalytic line	1
10	33141002	guide rail bracket fixing axis	4
11	33310003	45 °C cooling fan thermostat	2
12	33313020	cooling fan assembly	1
13	33033017	side plate (left&right)	2
14	33303006	top heating element	1
15	33301035	function switch (5 function)	1
16	33311018	temperature selector	1
17	33300011	sensor touch timer (3 button)	1
18	33301034	function switch (4 function)	1
19	33312001	indicator light	2
20	33311008	temperature selector	1
21	33018148	fixing panel for switch	1
22	33006001	connect board	4
23	33007171	control panel front board	1
24	33101382	control panel assembly	1
25	32244031	21 # knob	4
26	33103023	inner glass(top door)	1
27	33014087	door frame top bracket	1
28	33014080	door frame left bracket	1
29	33190010	hanld H7	1
30	33102370	door panel	1
31	33015288	door panel decorated board	2
32	33014079	door frame right bracket	1
33	33180018	12 # hinge assembly	2
34	33014049	fixing panel for inner glass	2
35	33014250	top bracket for oven door	1
36	33190010	hanld H7	1
37	33014084	door frame left bracket	1
38	33102465	door panel	1
39	33015286	S.S trim for door panel	2
40	33006012	fixing board for handle	2
41	33014083	door frame right bracket	1
42	33180019	13 # hinge assembly	2
43	33103029	inner glass	1
44	33172001	handle for rack	2
45	33024006	side bracket for cavity(left&right)	2
46	33005014	Hinge Retainer	2
47	33170003	tray grill	1
48	33224003	tray	1
49	33170001	grill rack	2
50	33803013	door seal assembly (B)	1
51	33803014	door seal assembly (C)	1
52	33303009	top heating element (for 5 function)	1
53	33237030	the support for bottom cover plate	4
54	36038003	side rack	2
55	33303040	rear heating element	1
56	33540001	side rack panel	2
57	33035001	thermostat switch sensor fixer	10