



Double oven:DOV90SS

Product reference code:DOV90SS


Modified by:Eason

Modification:

00_2018.01.24 New document

01_2018.01.29 Add door assembly part number

DOV90SS Exploded drawing



DOV90SS parts list

No.	ref. part code	factory part code	Part Name	QTY
1	60101195	1421025002	power cord	1
2	60703550	1421600102	power box	1
4	62101105	1421200210	thermostat 145°C	1
6	25107860	1420700109	lamp	2
8	25108305	1420500124	top heater(top oven)	1
9	64900945	1420900218	motor (cooling fan)	1
13	62101110	142120010801	thermostat (50°C)	2
19	25108310	1120500117	Side Shelf(top oven)	2
20	25107980	1120500101	big grill rack	2
23	60501485	1320200701	door seal(top)	1
25	62101115	1421100204	Liquid expansion thermostat	1
26	25108315	142020011001	switch(four stalls)	1
27	25108320	1420400109	#3 indicator	2
29	69416230	2124910024	bottom plate of control panel	1
30	63900460	142140010501	display	1
32	69416235	21201013004	stainless Steel control panel	1
33	60703465	1320100151	knob	4
35	69416240	1120100214	middle glass(top oven)	1
37	62902195	1120400601	door hinge	2
36+'38+43	69416245	212740160201 +112010019001 +212740160101	outer door glass assembly(top oven)	1
40	60703440	1122400122	handle	2
45	69416250	1120100348	inner glass(top oven)	1
46	60703555	132030010301	Timer keys	6
48	25108330	142020010301	switch(four stalls)	1
49	62101120	142110010502	Liquid expansion thermostat	1
53	25107995	1120500306	Side Shelf	2
54	25108335	1420500309	circle heater	1
55	62902200	212030030101	fan cover	1
56	60501490	1320200702	door seal	1
58	69411440	1120100349	inner glass(bottom oven)	1
59	69411445	1120100215	middle glass(bottom oven)	1
60+'61+63	69411450	212740160301 +112010013312 +212740160401	Outer glass assembly(bottom oven)	1
62	25107920	1120400110	outer door hinge assembly	2
64	25107985	212210010101	Food tray	2
65	25108340	2121700301	bottom heater plate	1
70	60703430	1320400101	handle	2
71	64900950	142090020303	circulating fan motor	1
72	62101125	1421200207	thermostat 110°C	1
73	25108820	1120500201	small grill rack	1
74	25108345	1420500106	upper heater	1
75	25108350	1420500221	bottom heater	1
77	25108815	2123800102	tray handle	1
34+35+36+37 +38+40+41+4 2+43+44+45+	69416270	212740080201 +1120100214 +212740160201 +1120400601 +112010019001 +1122400122 +2127700302 +2127700301 +212740160101 +2127401205 +1120100348	Complete door assembly(upper)	1
34+40+41+42 +44+58+59+6 0+61+62+63	69416275	212740080201 +1122400122 +2127700302 +2127700301 +2127401205 +1120100349 +1120100215 +212740160301 +112010013312 +1120400110 +212740160401	Complete door assembly(below)	1

DOV90SS Wiring diagram

