


Cooker Hood
Model Number
UBSDCH90W
Parts Manual

Exploded Drawing



Parts List

ID No	Part Number	Part Description	Qty
22	1.01.06.0008	REMOTE CONTROL	1
21	1.11.01.0004	CARBON FILTER FOR OPTIONAL	2
20	1.02.10.0044	LIGHT WIRE	1
19	2.03.09.0054	POWER CORD ASSEMBLY (WITHOUT PLUG)	1
18	2.03.10.0001	CAPACITOR	1
17	2.03.02.0104	PCB BOARD ASSEMBLY	1
16	1.04.03.0001	POWER BOX BASE	1
15	1.04.03.0007	POWER BOX COVER	1
14	2.03.06.0115	M13 MOTOR ASSEMBLY	1
13	1.03.12.0001	ALUMINUM FILTER	2
12	2.03.01.0638	INSTALL THE BRACKET ASSEMBLY	4
11	1.12.01.0005	MAGNET	2
10	1.04.10.0021	MAGNET BASE	2
9	2.01.06.0493	RIGHT BRACKET	1
8	2.01.06.0492	LEFT BRACKET	1
7	2.01.06.0460	REINFORCEMENT BAR	2
6	2.01.06.0461	SUPPORT BAR	2
5	2.03.07.0008	LED LIGHT PANEL ASSEMBLY	1
4	2.01.07.0134	PANEL	1
3	2.01.14.0223	HOUSING ASSEMBLY	1
2	2.01.02.0042	CASING HOARDING	1
1	2.01.01.0028	CASING TOP BOARD	1