


Cooker Hood
Model Number
UBCML100W
Parts Manual

Exploded Drawing



Parts List

ID No	Part Number	Apelson Code	Spare Part Description	Qty
1	1130402941	1130402941	HANGING BOARD	1
2	1130205580	1130205580	CAVITY RIGHT DECORATIVE PANEL	1
3	1130205578	1130205578	CAVITY FTONT/REAR DECORATIVE PANEL	2
4	1130205579	1130205579	CAVITY LEFT DECORATIVE PANEL	1
5	1130402940	1130402940	BLOWER FIXED PLATE	1
6	12001010300223	AA0000002079	BLOWER BUTTOM	1
7	1400200768	1400200768	MOTOR	1
8	1309800354	1309800354	IMPELLER	1
9	12001010300224	AA0000002080	BLOWER COVER	1
10	1139804175	1139804175	WELD ASSEMBLY OF INNER OUTLET(SET)	1
11	1130402946	1130402946	INNER OUTLET BRACKET	2
12	1149800006	1149800006	CAVITY HANGING BAR ASSEMBLY(SET)	4
13	138DCAS	138DCAS	CASING ASSEMBLY(SET)	1
14	1309800248	1309800248	MAGNET RING	4
15	1309800353	1309800353	INLET MESH	1
16	1309800352	1309800352	SLIDE RAILS	4
17	138DWC	138DWC	WIRE COVER	2
18	1400400024	1400400024	POWER CORD	1
19	12001010200229	AA0000001328	JUNCTION BOX	1
20	1400500811	1400500811	PCB BOARD	1
21	12001010200228	AA0000001329	JUNCTION BOX COVER	1
22	1130205581	1130205581	CASING BAFFLE	1
23	1130205576	1130205576	FRONT LAMP COVER	1
24	1130402943	1130402943	LED LIGHT STRIP BRACKET	4
25	1400600556	1400600556	LED LIGHT STRIP	2
26	1400600557	1400600557	LED LIGHT STRIP	2
27	12001010200351	AA0000002081	SWITCH BOX COVER	1
28	1400500812	1400500812	TOUCH CONTROL	1
29	138DFGAS	138DFGAS	FRONT GLASS ASSEMBLY(SET)	1
30	1130205577	1130205577	REAR LAMP COVER	1
31	138DRGAS	138DRGAS	REAR GLASS ASSEMBLY(SET)	1
32	1300100750	1300100750	ALUMINIUM FILTER WITH INSERTED CARBON FILTER PAPER	4
33	1400500350	1400500350	REMOTE CONTROL	1
34	138DSB	138DSB	SCREW BAG	1