


Cooker Hood
Model Number ICONBOX60
Parts Manual

Exploded Drawing.



Parts List

S/N	Ref.	Description	QTY
1	B23-TG18-010-PX	Upper chimney bracket	1
2	B20-TT06-016-PX	Upper chimney	1
3	B23-TG18-009-PX	Lower chimney bracket	1
4	B20-TT06-015-PX	Lower chimney	1
5	B67-TY04-005-XB	Wire only, without plug	1
6	B67-TY03-278-XX	Switch wire	1
7	B67-TY03-263-XB	Light wire	1
8	B30-TG18-017-JB	Electric control box	1
	B30-TG18-016-JB		1
9	B23-TG18-027-PX	Wall bracket	1
10	B63-TY07-266-XX	Switch-T13	1
11	B33-TT06-104-XB	Switch glass-black	1
12	B20-TT06-002-PX	Rear decorative plate	1
13	B20-TT06-001-PX	Front light shade	1
14	B62-TY01-016-XX	LED lamp	2
15	B35-TG01-036-XX	Aluminium filter	2
16	B30-TG18-015-JB	Φ150 valve	1
17	B30-TD01-017-JB	Housing D -left part	1
18	B30-TT03-012-JB	Fan	1
19	B61-TY02-028-XX	Housing D motor	1
20	B30-TV05-019-JB	Housing D -right part	1
21	B15-TF08-097-JB	Charcoal filter	2
22	B63-TY07-015-XX	TM07D PCB	1