



Dish Washer : DWIB60					
S/N	ref	Description	Qty	Midea item number	Midea internal code (only for reference)
1	69403590	External pipe-dish washer-DW60W	1	1001	673000900249
2	61900130	O Ring 131.5X3.55-dish washer-DW60W	2	1002	673001500005
3	60701530	Guide casing-dish washer-DW60W	1	1003	673001800010
4	63500105	External pipe nut-dish washer-DW60W	1	1004	673001600012
5	69403595	Water dispenser-dish washer-DW60W	1	1005	673001900012
6	69406465	Upper sprayer-dish washer-DWIB60	1	1006	673000300066
7	69403600	Upper sprayer pipe-dish washer-DW60W	1	1007	673000900194
8	60701535	Float holder-dish washer-DW60W	1	1010	673002300002
9	69403615	Float-dish washer-DW60W	1	1012	673002300003
10	69403610	Micro switch-dish washer-DW60W	1	1013	674000300060
11	69403630	Micro filter-dish washer-DW60W	1	1016	673002500054
12	69403640	Sump nut-dish washer-DW60W	1	1017	673001600008
13	61900135	Sump gasket-dish washer-DW60W	1	1018	673001500016
14	69406470	Sump -dish washer-DWIB60	1	1019	673000700082
15	69406475	Clamp 12.7×1.8-dish washer-DWIB60	1	1020	672000700028
16	69403765	PVC hose-dish washer-DW60W	1	1022	673000900073
17	69406480	pressure switch-dish washer-DWIB60	1	1023	674000300090
18	69406485	Drain pump-dish washer-DWIB60	1	1027	674000600106
19	69403680	Salt filler-dish washer-DW60W	1	1029	673002200043
20	69403685	Softener cover assembly-dish washer-DW60W	1	1030	673002800054
21	61900140	Softener cover gasket-dish washer-DW60W	1	1031	673001700053
22	63500110	Softener nut-dish washer-DW60W	1	1032	673001600028
23	61900145	Softener gasket-dish washer-DW60W	1	1033	673001700001
24	69406490	Softener-dish washer-DWIB60	1	1034	674000700022
25	69403690	Softener pipe-dish washer-DW60W		1035	673000900224
26	69403840	Clamp 14.5×1.8-dish washer-DW60W	3	1036	672000700029
27	69406495	Drain hose hook-dish washer-DWIB60	1	1037	673006200027
28	69403720	Drain hose holder-dish washer-DW60W	1	1038	673001500002
29	69406500	Drain hose-dish washer-DWIB60	1	1039	673000900186
30	25102770	Power cord-dish washer-DW60W	1	1042	674000000194
31	69406505	Inlet valve-dish washer-DWIB60	1	1043	674000200012
32	25102775	Inlet hose assembly-dish washer-DW60W	1	1045	673000900060
33	69403820	Regeneration hose-dish washer-DW60W	1	1046	673000900026
34	69403825	Softener pipe-dish washer-DW60W		1047	673000900224
35	69403830	Inlet hose of air breather-dish washer-DW60W	1	1048	673000900024
36	63500120	Air breather nut-dish washer-DW60W	1	1051	673001600002
37	25102795	Air breather assembly-dish washer-DW60W	1	1054	673002700001
38	69406510	Lower sprayer-dish washer-DWIB60	1	1064	670400051613
39	25102780	Washing pump-dish washer-DW60W	1	1070	674000600047
40	25102785	Washing motor support A-dish washer-DW60W	1	1071	672000200054
41	25102790	Washing motor support B-dish washer-DW60W	1	1072	672000200054
42	69403770	Connect hose a-dish washer-DW60W	1	1074-a	673000900140
43	69403785	Connect hose b-dish washer-DW60W	1	1074-b	673000900182
44	69406515	Bend connect hose-dish washer-DWIB60	1	1083	673000900045
45	69403635	Heating element support-dish washer-DW60W	1	1085	673001400025
46	69403740	Heating elements-dish washer-DW60W	1	1086	674001100039
47	63500125	Water inlet nut-dish washer-DW60W	1	1088	673001600009
48	61900155	Water inlet gasket-dish washer-DW60W	1	1089	673001500019
49	69403850	Water inlet-dish washer-DW60W	1	1091	673002600035
50	69403650	Sensing device-dish washer-DW60W	1	1093	674000900038
51	69403625	plane filter-dish washer-DW60W	1	1113	673002500048
52	69403620	Scran collection-dish washer-DW60W	1	1114	673001300136
53	69403750	Pressure switch-dish washer-DW60W	1	1115	674000300079
54	69403715	power cord clasper-dish washer-DW60W	1	1116	673001400083
55	69403735	pressure switch assembly for heating elements-dish washer-DW60W	1	1117	674000300067
110	69403695	OTK 175-dish washer-DW60W	4	OTK 175	672000700004
111	69406690	OTK 286-dish washer-DWIB60	1	OTK 286	672000700003
112	69403655	OTK 310-dish washer-DW60W	6	OTK 310	672000700001
113	69403775	OTK 396-dish washer-DW60W	3	OTK 396	672000700007

					<div><div>cata</div><div>ELECTRODOMESTICOS S.L.</div></div>		Name:	Date:	Material:	Model:	
						Drawn:	Bon.Liu	2009.09.24	Weight:	DWIB60	
						Checked:			Colour:	N°Pieces	Reference:
						Page:	page1		Destiny:	101	
01	add a ref code for No.114 on page 3	Bon.Liu	2010.10.26	01	<div><div><div></div><div></div></div><div>DIM without tolerance</div><div>.....6 >6...30 >30...120 >...120</div><div>±0.1 ±0.2 ±0.3 ±0.5</div></div>	Scale:	Denomination:				
00	Creación Documento/New Document	Bon.Liu	2009.09.24	00		-/-	DWIB60-01-break down drawing-dish washer-DWIB60				
Index	Modify Description	Modified by:	Date	Mod:							



Dish Washer : DWIB60					
S/N	ref	Description	Qty	Midea item number	Midea internal code (only for reference)
56	69406520	Door edge guard piece-dish washer-DWIB60	2	2001	673002000042
57	69406525	Inner door -dish washer-DWIB60	1	2002	672002200142
58	69406530	Dispenser bracket-dish washer-DWIB60	2	2004	672001700002
59	69406535	Dispenser-dish washer-DWIB60	1	2005	674000800031
60	25102755	Wiring harness-dish washer-DW60W	1	2006	674000100390
61	69406540	Ring Φ6-dish washer-DWIB60	4	2008	672000500006
62	25102815	Left hinge-dish washer-DW60W	1	2009	672001300029
63	69406545	Joint pin-dish washer-DWIB60	2	2010	672001200012
64	25102810	Right hinge-dish washer-DW60W	1	2011	672001300030
65	25102805	Door gemel assembly-dish washer-DW60W	1	2012	672001300024
66	69406550	Door spring-dish washer-DWIB60	2	2013	672000100008
67	69406555	Outer door-dish washer-DWIB60	1	2017	672001800315
68	69406560	Control panel-dish washer-DWIB60	1	2018	673000404807
69	69406565	Handle assembly-dish washer-DWIB60	1	2023	673001800513
70	69406570	Door switch-dish washer-DWIB60	1	2024	674000300069
71	69406575	Power switch-dish washer-DWIB60	1	2027	674000300065
72	69406580	Control assembly-dish washer-DWIB60	1	2034	674001020418
73	69406585	film-dish washer-DWIB60	1	2035	
74	69403900	Control board box-dish washer-DW60W	1	2036	673002400095
75	69406590	Screw sleeve-dish washer-DWIB60	2	2040	673001800018
76	69406595	Sleeve cover-dish washer-DWIB60	2	2041	673000700005
77	69406600	Control panel cover-dish washer-DWIB60	1	2053	673002800041
78	69406605	Power button-dish washer-DWIB60	1	2950	673000800903

					<div><div>cata</div><div>ELECTRODOMESTICOS S.L.</div></div>	Name:	Date:	Material:	Model:		
						Drawed:	Bon.Liu	2009.09.24	Weight:	DWIB60	
						Checked:			Colour:	N°Pieces	Reference:
						Page:	page2		Destiny:	DWIB60	
01	add a ref code for No.114 on page 3	Bon.Liu	2010.10.26	01	<div><div><div></div><div></div></div><div>DIM without tolerance</div><div>.....6 >6...30 >30...120 >...120</div><div>±0.1 ±0.2 ±0.3 ±0.5</div><div>Dimenions in mm</div></div>	Scale:	Denomination:				
00	Creación Documento/New Document	Bon.Liu	2009.09.24	00		-/-	DWIB60-01-break down drawing-dish washer-DWIB60				
Index	Modify Description	Modified by:	Date	Mod:							



Dish Washer : DWIB60					
S/N	ref	Description	Qty	Midea item number	Midea internal code (only for reference)
79	69406610	Left side panel-dish washer-DWIB60	1	3001	672001600212
80	69404065	Upright left assembly-dish washer-DW60W	1	3003	672002100058
81	69403950	Upper rear crosspiece-dish washer-DW60W	1	3005	672001500008
82	69406615	Door lock-dish washer-DWIB60	1	3007	672001400039
83	69406620	Upper front crosspiece-dish washer-DWIB60	1	3009	672001500246
84	69403980	Tank gasket-dish washer-DW60W	1	3010	673001700057
85	69403970	Upright right assembly-dish washer-DW60W	1	3011	672002100057
86	69406625	Right panel-dish washer-DWIB60	1	3012	672001600211
87	69406630	Upper basket cup holder-dish washer-DWIB60	4	3013	673001300101
88	25102855	Cutlery basket-dish washer-DW60W	1	3014	673002200098
89	25102835	Lower basket-dish washer-DW60W	1	3017	672000801060
90	25102830	Upper basket-dish washer-DW60W	1	3018	672000801059
91	69403990	Rail block-dish washer-DW60W	2	3021	673001300047
92	69403995	Rail-dish washer-DW60W	1	3022	672001700005
93	69404000	Rail support assembly-dish washer-DW60W	4	3023	673001400075
94	69406635	Lower front crosspiece-dish washer-DWIB60	1	3027	672001500303
95	69406640	Base board-dish washer-DWIB60	1	3029	672002000066
96	69404040	Tank band bracing block-dish washer-DW60W	2	3032	673001700010
97	69404045	Lower rear crosspiece-dish washer-DW60W	1	3033	672001500202
98	69404050	Middle rear crosspiece-dish washer-DW60W	1	3034	672001500007
99	25102860	Measurable spoon-dish washer-DW60W	1	3035	673002200079
100	69406645	Adjust steel rope-dish washer-DWIB60	2	3048	672001100004
101	69406650	Adjust nut-dish washer-DWIB60	2	3049	672002300002
102	69406655	Top board hook-dish washer-DWIB60	2	3050	673001300012
103	69406660	Adjust screw-dish washer-DWIB60	2	3051	672001100003
104	69406665	Right adjuster holder assembly-dish washer-DWIB60	1	3052	673001400146
105	69406670	Front foot-dish washer-DWIB60	2	3053	672001400045
106	69406675	Adjustable pole-dish washer-DWIB60	2	3055	672001100002
107	69406680	Left adjuster holder assembly-dish washer-DWIB60	1	3056	673001400145
108	69406685	Back foot-dish washer-DWIB60	2	3057	672001400046
109	25102845	Rinsing agent cup-dish washer-DW60W	1	C5004	673006200004
114	69406910	cavity--dish washer-DWIB60	1		

01	add a ref code for No.114 on page 3	Bon.Liu	2010.10.26	01
00	Creación Documento/New Document	Bon.Liu	2009.09.24	00
Index	Modify Description	Modified by:	Date	Mod:

cata		Name:	Date:	Material:	Model:
ELECTRODOMESTICOS S.L.		Drawn:	Bon.Liu	2009.09.24	DWIB60
		Checked:		Weight:	N°Pieces
		Page:	page3	Colour:	Reference:
		Scale:	-/-	Destiny:	DWIB60
		Denomination:			
		DWIB60-01-break down drawing-dish washer-DWIB60			