




Electric Oven: EOS60SS

Version:05

Date:2014-10-20

Product reference code: EOS60SS

# EOS60SS Exploded drawing



05	Update No. 25	Eason	2014. 10. 20
Index	Modify description	Modified by	Date

# EOS60SS parts list

48	25103075	complete door-oven-EOS60SS	1	Assembly parts
47	45400070	Internal grill	1	A3
46	45400075	Tray holder	1	A3
45	25100140	Lower resistance 1300W SE604I/B	1	Chromiun plated steel pipe
40	20103105	Power wire H07RN-F 3x1.5mm L=160cm	1	assembly parts
39	20103103	Power box Asm.	1	assembly parts
32	20102957	lampholder group	1	
31	25100135	oven lamp 300T 25W	1	
30	20104070	oven bulb protector glass	1	Tempered glass
25	25101485	Temperature controller general 115°C oven SE604I/B	1	assembly parts
21	20103123	Plate	1	SPP.R35 enamel
20	20102975	Alarm L30 SE604I/B	1	assembly parts
19	20103117	green Pilot light	1	assembly parts
18	20103115	yellow Pilot light	1	assembly parts
17	25100130	Thermostat(L37) SE604I/B	1	assembly parts
16	25100125	Function switch L30 (4+0) SE604I/B	1	assembly parts
15	25100120	Upper resistance900+1350W SE604I/B	1	Chromiun plated steel pipe
14	60700215	gasket rubber	4	Silicone rubber
13	25105595	Control panel-oven-EOS60SS2	1	430 S.steel
12	20102968	V10 knob black ME609DI	3	PF
10	60700205	Door handle ECO604	1	PE
9	20103133	door press piece-oven-EOS60SS	4	PA
7	20103120	hinge-oven-EOS60SS	2	assembly parts
5	20103134	internal glass-oven-EOS60SS	1	glass
3	20103132	Gum door ASM. "□"	1	Silicone rubber Asm.
S/N	REF	DESCRIPTION(en)	QTY	MATERIAL