




**electrical oven:KC567MFS**

**Version: 00**

**Date: 2014-04-21**

KC567MFS Exploded drawing



00	New document	Paul	2014-4-21
Index	Modify description	Modified by	Date

KC567MFS Parts list			
No.	Part code	Part description	Quantity
3	33311013	thermostat (290°)	1
4	33313019	cooling fan assembly	1
7	33303032	rear grill (1100W)	1
9	33315002	convection fan	1
12	33305002	wire terminal	1
13	33304077	power cord	1
14	33035001	temperature clip	2
16	33323001	temperature sensor	1
17	33317001	lamp	2
21	33005004	hinge receiver	2
22	33058058	cavity assembly	1
23	33303039	bottom grill	1
26	33018095	door frame assembly	1
28	33170001	shelf	2
29	33224003	tray	1
30	33170003	shelf in tray	1
32~46		door assembly_KC567MFS	
33	33103018	inner glass	1
34	33014010	left hinge support	1
35	33104022	middle glass	1
39	33190007	handle	1
40	33014019	right hinge support	1
41	33180008	hinge assembly	2
47	33172001	handle for tray & shelf	1
48	33140008	right oven grille	1
49	33140007	left oven grille	1
53	33101247	glass panel	1
54	33133003	socket	1
57	33322008	display PCBA box	1
60	33301020	micro-switch	1
62	33322007	power PCBA box	1
64	33321054	display PCBA	1
65	33321027	power PCBA	1
66	33803002	door sealing	1
68	33303041	top grill (1100~1600W)	1