




Oven:UBOVFM60

Version:00

Date:2014-10-25

Product reference code: UBOVFM60

UBOVFM60 Exploded drawing



00	New document	Eason	2014. 10. 25
Index	Modify description	Modified by	Date

# UBOVFM60 parts list

No.	Part Code	Part name English	Qty
A23	261500616702	front plate	1
A35	262101400124	cavity sealing ring	1
A49	261561500800	encloser(Right)	1
A50	261561400800	encloser(Left)	1
C13	261561900400	control panel back cover	1
C16	261561800600	control panel cover	1
C32	261517208400	power cord bracket	1
G07	261201002601	power cord	1
G16	291201300003	cooling fan motor	1
G21	261201301110	thermostat	1
G21	261201301240	thermostat	1
H02	291400200002	power board	1
I01	291599900023	fastener assembly	1
I09	261561700400	Following encloser	1
I29	261561600400	back cover	1
I46	261561201602	top cover	1
I48	261331200200	handle box	2
I63	261504501200	hinge fixed frame (Right)	1
I64	261504501100	hinge fixed frame (Left)	1
A00	\	cavity ass'y	
A12	291501300006	bake rack	1
A15	291501400002	bake tray	1
A30	291504600169	cavity	1
A32	262100600066	Cavity insulation	1
A42	261562000402	convection motor cover	1
A43	261508200600	convection fan blade	1
A53	291200800008	under heating element cover	1
A61	291200800014	metal heating element*(top)	1
A62	261201702190	turbo heating element	1
D13	291504200016	Rail bracket (Right)	1
D14	291504200015	Rail bracket (Left)	1
G10	261257700038	lamp	1
G18	261204100130	convection motor	1
G20	263004100034	temperature sensor	1
I19	261564600300	insulation cover	1
I26	262100600063	back insulation	1
I40	261564400600	exhaust pipe	1
B00	293600106885	door ass'y	1
B01	292100900002	door handle cushion	2
B02	291300600021	handle support	2
B06	291501700003	door decoration	1
B11	291502100015	door hinge ass'y	2
B12	291502200107	door handle	1
B13	262155000003	door inner glass	1
B17	291599900004	door glass spring piece	2
B20	291502400002	door frame up cover	1
B21	291399900003	door frame top decorate(Right)	1
B22	291399900004	door frame top decorate(Left)	1
B24	291504200049	door frame bracket(Right)	1
B25	291504200048	door frame bracket(Left)	1
B26	291800800516	door outer glass	1
I35	291504200003	hinge bracket(Right)	1
I36	291504200006	hinge bracket(Left)	1
I53	292100800005	rubber gasket	6
C00	293600106886	control panel ass'y	1
C01	291599900056	button	1
C02	261358201900	button bracket	2
C03	261312501700	button skirt	4
C11	261561001702	control panel holder	1
C12	292100300002	control panel sponge	2
C14	292100400001	film of control panel	1
C15	291501700003	control panel decoration	1
C17	261563800900	control panel bracket	2
C20	291800800517	control panel glass	2
C26	261313002600	display bracket	1
C29	261312505500	skirt cramp	4
C30	291301000068	Knob Assembly	2
H01	291400100022	display board	1
I20	291504200043	stator	2