




**electrical-gas oven:KC567GMM**

**Version: 00**

**Date: 2014-03-25**

## KC567GMM Exploded drawing



00	New document	Paul	2014-3-25
Index	Modify description	Modified by	Date

# KC567GMM Parts list

No.	Part code	Part description	Quantity
1	33313002	cooling fan assembly	1
2	32304002	ignition impulse devise	1
3	33035001	sensor clip	2
4	33229002	gas tube	1
5	33030003	back casing	1
6	33305002	connection box	1
7	33304077	power cord	1
8	33121002	glass fibre	1
9	33016001	back bracket	1
10	33302002	lamp assembly	1
11	32160028	intake tube	1
12	33319001	side spring	3
13	33229001	bottom gas tube	1
14	33120002	heat prevention glass fiber	1
15	33049001	fixing plate	1
16	33018116	fixing plate for gas tube	1
17	33058073	door frame assembly	1
18	33025004	left bracket for oven cavity	1
19	33005004	hinge reciver	2
20	32312036	thermocouple	1
21	32300017	ignition pin	2
22	33227001	nozzle fixing base	2
23	33228001	ignition pin base	4
24	33192038	lower NG nozzle (1.18)	1
	32192028	lower LPG nozzle (0.77)	1
25	33803001	door sealing assembly	1
26	33804001	lower flame distributor	1
27	33046001	flame distributor fixing plate	1
28	33029001	bottom casing	1
29	33224003	tray	1
30	33048001	flame distributor flapper	1
31	33103012	inner glass	1
32	33014017	right glass bracket	1
33	33180009	hinge assembly	2
34	33014018	right hinge support	1
35	33104014	inner glass	1
36	33015231	door panel	1
37	33102241	door glass	1
38	33190007	handle	1
39	33214002	washer	2
40	33219004	rubber strip	1
41	33014013	left hinge reciver	1
42	33014016	left glass bracket	1
43	33219003	rubber strip	1
44	33014020	upper door bracket	1
45	33170001	rack	1
46	33172001	lateral handle	1
47	32244031	knob	3
48	33170003	tray rack	1
49	33007110	control panel decorative board	1
50	33101105	control panel	1
51	91034002	Single-sided plastic	1
52	33006001	control panel fixing bracket	4
53	33307002	count down timer	1
54	33301014	function selector	1
55	33312002	indicator light	1
56	33232002	valve	1
57	33033002	left oven casing	1
58	33032002	right oven casing	1
59	33214001	washer	2
60	33804007	upprrt flame distributor	1
61	33024004	left bracket for oven cavity	1
62	33027001	bottom plate for cooling fan	1
63	32192084	upper NG nozzle (0.93)	11
	32192069	upper LPG nozzle (0.65)	1
64	33215004	lower cooling fan casing	1
65	33215003	upper cooling fan casing	1
66	33310001	thermostat for cooling fan (65℃)	1
67	32312024	upper thermocouple	1
68	33026006	upper cooling fan plate	1
69	33308014	cut-out thermostat (150℃)	2
70	33031001	up oven casing	1
71	33313007	cooling fan flapper	1