




Exploded Drawing and Parts List

Model
CLPYST



Oven install screws part number 291599900023



ID No	Part Description	Qty	Part Number
G07	power cord	1	17471100000108
H02	Power board assy	1	17171100001080
I41	exhaust seat	1	12171100001195
G14	Door lock	1	17471100000551
I36	hinge bracket(left)	1	12971100000534
A50	Enclose Left)	1	12271100005348
G21	thermostat	2	17471100000217
C13	control panel back cover	1	12271100005023
C16	control panel cover	1	12271100005021
G16	cooling fan motor	1	17471100002273
I46	top cover assy	1	12271100005345
I29	back cover	1	12271100005233
A49	Enclose (right)	1	12271100005347
I48	handle box	2	12171100000284
I09	following enclose	1	12271100005346
I63	hinge bracket (right)	1	12971100000470
A23	front plate	1	12271100007425
A35	cavity sealing ring	1	12671100000073
A08	pylons	1	12971100002588
A08	pylons	1	12971100002583
A15	bake tray	1	12271100003074
A61	metal heating element*(top)	1	17471100000574
A12	bake rack	1	12971100000644
I40	exhaust pipe	1	12271100003108
I19	insulation cover	1	12271100005013
I26	back insulation	1	12471100000041
A32	cavity insulation	1	12471100000010+12471100000050
A30	cavity	1	12271100002827
A53	under heating element cover	1	17471100001474
A62	turbo heating element	1	17471100000261
A43	convection fan blade	1	12971100001067
A42	convection motor cover	1	12271100002160
G10	lamp	1	17471100000586

B00	Complete Door Assembly	1	CLPYSTXDR
B02	handle support	2	12171100000172
I36	hinge bracket	1	12971100010682
B11	door hinge ass'y	2	12971100010681
B34	Door support bracket left	1	12171100001414
B20	door frame up cover	1	12171100001197
B13	door inner glass	1	12571100001931
B28	door middle glass(1)	1	12571100000359
B29	door middle glass(2)	1	12571100000362
I53	rubber gasket	4	12671100000096
B35	Door support bracket right	1	12171100001415
B24	door frame bracket(right)	1	12971100004105
B25	door frame bracket(left)	1	12971100004107
B08	DOOR DECORATION	1	12271100002208
B26	door outer glass	1	12571100000991
B12	door handle	1	12971100002616
C00	Complete Control Panel Assembly	1	CLPYSTXCP
C01-2	button assy	1	12171100001416
C01-1	button	4	12171100001216
C26-2	display bracket 2	1	12171100000886
C26-1	display bracket 1	1	12171100001214
H01	display board	1	17171100000217
C11	control panel holder	1	12271100007945
C17	control panel bracket	2	12971100004148
C12	control panel sponge	2	12471100000054
C20	control panel glass	1	12571100001930
C15	control panel decoration	1	12271100008105
C30	knob	2	12171100000788