




Fridge :TPFSW60LF

Version:01

Date:2015-09-24

Product reference code:TPFSW60LF

TPFSW60LF Exploded drawing



00	New document	Eason	2014. 6. 7
Index	Modify description	Modified by	Date

TPFSW60LF parts list

No.	part code	part description	Quantity
1	228010002493	On hinged cover	1
2	571000090529	Philips Hex head screw	3
3	208010001676	top hinge	1
4	208010002401	Cabinet foamed assy	1
5	228010002494	The hinge panel	1
6	571000090527	Philips Hex head screw	1
7	228010000142	Shake handhandle buckle fixed plate	1
8	228010000462	Freezer Door Seal	1
9	208010000570	Freezer door	1
10	258010000022	thermostat	1
11	228010001870	temperature control knob	1
12	228010001665	thermostat box cover	1
13	258010000005	Lamp base	1
14	258010000002	lamp	1
15	228010000718	Lamp-thermostat socket	1
16	571000090524	Cross slot round head wood screws 4*25	1
17	228010001665	Lamp cover	1
18	228010000215	Fridge Door Seal Assy	1
19	208010002318 (W)	Fridge door	1
20	228010001082	Content waring column	3
21	228010001409	vegetable box	1
22	208010000565	vegetable box cover	1
23	208010000118	Shelf	1
24	571000090529	Philips pan head self-drilling screw	2
25	228010000637	door axle bed	1
26	228010000796	axle sleeve	1
27	228010000063	Adjust leg	2
28	208010000347	bottom hinge	1
29	571000090527	Philips hex head flange head off tapping screw	3
30	258010000013	Light switch	1
31	571000090527	Philips hex head flange head off tapping screw	4
32	218010000319	Compressor base plate	1
33	208010000434	Shock absorber rubber ring	4
34	571000090525	Philips pan head triangel plum locknut screw	2
35	258010000043	Earth wire	1
36	228010002661	Vaporizing case	1
37	288010000165	Compressor	1
38	218010000330	Compressor pressure plate	2
39	571000090525	Philips pan head triangel plum locknut screw	1
40	258010001725	power cord	1

