




Oven:UBMFM60SS

Version:00

Date:2014-08-14

Product reference code: UBMFM60SS

UBMFM60SS Exploded drawing



00	New document	Eason	2014. 8. 14
Index	Modify description	Modified by	Date

UBMFM60SS parts list

No.	part code	part description	Qty
1	33027005	exhausting pipe base board	1
2	33027008	the block for exhausting pipe base board	1
3	33311013	temperature protector (290 degree)	1
4	33313019	cooling fan assembly	1
5	91127002	insulation paper for cooling fan	1
6	33215007	exhausting pipe	1
7	33303032	rear heating element	1
8	33016002	back support for cavity	1
9	33315002	circulating fan assembly	1
10	33030011	back cover plate	1
11	33004010	temperature protector holder	1
12	33305002	terminal box	1
13	33304077	power cable	1
14	33035001	thermostat switch sensor fixer	2
16	33323001	temperature sensor assembly	1
17	33317001	square lamp assembly	2
18	33141005	fixing base for side rack panel	4
19	33039005	removeable side panel (right)	1
20	33039004	removeable side panel (left)	1
21	33005004	fixing panel for hinge	2
22	33058058	cavity assembly	1
23	33303039	bottom heating element	1
24	33003002	the fixing panel for bottom heating element	1
25	33029009	bottom plate	1
26	33018095	Inner bladder panel	1
27	33001029	the cover plate for rear heating elment	1
28	33170001	grill rack	2
29	33224003	baking tray	1
30	33170003	the grill rack for baking tray	1
32	33014014	left fixing panel for oven door glass	1
33	33103018	inner glass	1
34	33014010	the fixing panel for left hinge	1
35	33104022	middle glass	1
36	33214005	the fixing part for handle	2
37	33015227	s.s trim for door panel	1
38	33102321	glass door panel	1
39	33190004	handle no.4	1
40	33014019	the fixing panel for right hinge	1
41	33180008	hinge assembly	2
42	33014001	Fixation for door panel	1
43	33219004	embedding strip for glass	1
44	33014015	right bracket for glass	1
45	33219003	top bracket washer	1
46	33014020	top bracket for oven door	1
47	33172001	the handle for grill rack	1
48	33140008	right side rack	1
49	33140007	left side rack	1
50	33032002	right side panel	1
51	33033002	left side panel	1
52	33007111	s.s trim for control panel	1
53	33101247	glass control panel	1
54	33133003	Socket assembly	1
55	33006006	the connect panel for control panel	4
56	33004009	fixing panel for door switch bracket	1
57	33322008	fixing box for display board	1
58	33005006	slide block for door stwich	1
59	33005005	fixing panel for door switch	1
60	33301020	door switch	1
61	33319002	the spring for door switch	1
62	33322007	The fixing bracket for PCB	1
63	33024004	lateral bracket (left)	1
64	33321054	display board	1
65	33321027	PCB	1
66	33803002	door seal assembly	1
67	33025004	lateral bracket (right)	1
68	33303041	top heating element	1
69	33031009	top cover board	1
70	33026007	exhausting pipe guard board	1
71	33028007	exhausting pipe cover board	1