

Gas Hob Model Number
CLGOGFSRP5

Parts Manual

This exploded view diagram illustrates the assembly of a multi-burner gas cooktop. The components are numbered as follows:

- 1**: Main cooktop body
- 2**: Front panel
- 3**: Control knob
- 4**: Control knob assembly
- 5**: Control knob cap
- 6**: Control knob cap
- 7**: Control knob cap
- 8**: Control knob cap
- 9**: Control knob cap
- 10**: Control knob cap
- 11**: Control knob cap
- 12**: Control knob cap
- 13**: Control knob cap
- 14**: Control knob cap
- 15**: Control knob cap
- 16**: Control knob cap
- 17**: Control knob cap
- 18**: Control knob cap
- 19**: Control knob cap
- 20**: Control knob cap
- 21**: Control knob cap
- 22**: Control knob cap
- 23**: Control knob cap
- 24**: Control knob cap
- 25**: Control knob cap
- 26**: Control knob cap
- 27**: Control knob cap
- 28**: Control knob cap
- 29**: Control knob cap
- 30**: Control knob cap
- 31**: Control knob cap
- 32**: Control knob cap
- 33**: Control knob cap
- 34**: Control knob cap
- 35**: Control knob cap
- 36**: Control knob cap
- 37**: Control knob cap
- 38**: Control knob cap
- 39**: Control knob cap
- 40**: Control knob cap
- 41**: Control knob cap
- 42**: Control knob cap
- 43**: Control knob cap
- 44**: Control knob cap
- 45**: Control knob cap
- 46**: Control knob cap
- 47**: Control knob cap
- 48**: Control knob cap
- 49**: Control knob cap
- 50**: Control knob cap
- 51**: Control knob cap
- 52**: Control knob cap
- 53**: Control knob cap
- 54**: Control knob cap
- 55**: Control knob cap
- 56**: Control knob cap
- 57**: Control knob cap
- 58**: Control knob cap
- 59**: Control knob cap
- 60**: Control knob cap
- 61**: Control knob cap
- 62**: Control knob cap
- 63**: Control knob cap
- 64**: Control knob cap
- 65**: Control knob cap
- 66**: Control knob cap
- 67**: Control knob cap
- 68**: Control knob cap
- 69**: Control knob cap
- 70**: Control knob cap
- 71**: Control knob cap
- 72**: Control knob cap
- 73**: Control knob cap
- 74**: Control knob cap
- 75**: Control knob cap
- 76**: Control knob cap
- 77**: Control knob cap
- 78**: Control knob cap
- 79**: Control knob cap
- 80**: Control knob cap
- 81**: Control knob cap
- 82**: Control knob cap
- 83**: Control knob cap
- 84**: Control knob cap
- 85**: Control knob cap
- 86**: Control knob cap
- 87**: Control knob cap
- 88**: Control knob cap
- 89**: Control knob cap
- 90**: Control knob cap

Parts List

Picture No	Component Number	Component Name	Amount
21	1200101316	BURNER BRIDGE	4
60	1200101774	BURNER BRIDGE FOR WOK BURNER	1
1	1200101767	BOTOM PLATE	1
9	1301000019	AUXILARY BURNER GAS VALVE	1
10	1301000020	SEMI-RAPID BURNER GAS VALVE	2
11	1301000021	RAPID BURNER GAS VALVE	1
12	1301000022	WOK BURNER GAS VALVE	1
14	1200101429	VALVE SHEET	1
23	1301100002	SEMI-RAPID BURNER CUP	2
24	1301100003	RAPID BURNER CUP	1
22	1301100004	AUXILARY BURNER CUP	1
25	1301100069	WOK BURNER CUP	1
82	1301900001	CHEESE - HEAD SCREW M4X15	10
85	1301900013	CHEESE - HEAD SCREW M3,5X6	10
13	1301201699	MAIN GAS PIPE	1
	1200101034	MAIN GAS PIPE SUPPORT PARTS	1
19	1301201651	GAS DISTRIBUTOR PIPE RIGHT-FRONT BURNER	1
18	1301201652	GAS DISTRIBUTOR PIPE RIGHT-REAR BURNER	1
59	1301201653	GAS DISTRIBUTOR PIPE WOK BURNER	1
17	1301201654	GAS DISTRIBUTOR PIPE LEFT-REAR BURNER	1
16	1301201655	GAS DISTRIBUTOR PIPE LEFT-FRONT BURNER	1
80	1301900005	CHEESE - HEAD SCREW M3,9X9,5	13
89	1301900007	NUT M6X0,75	5
7	1300401009	BENDS CONE	1
8	1301900011	GASKET KLINGRIK	1
2	1300501026	LEAKPROOFING GASKET	1
3.1	1200101011	SHRINKING HOOK	4
3.2	1301900031	CHEESE - HEAD SCREW M4,2x40	4
	1300401003	INJEKTOR 0.50mm AUX LPG (G30-28-30mbar G31-37mbar)	1
	1300401004	INJEKTOR 0.65mm SR LPG (G30-28-30mbar G31-37mbar)	2
	1300401005	INJEKTOR 0.85mm R LPG (G30-28-30mbar G31-37mbar)	1
	1300401037	INJEKTOR 1.01mm TC4 LPG (G30-28-30mbar G31-37mbar)	1
	1300401085	INJEKTOR 0.53mm AUX LPG (G31-28-30mbar)	1
	1300401086	INJEKTOR 0.69mm SR LPG (G31-28-30mbar)	2
	1300401077	INJEKTOR 0.90mm (AUX NG G20-10mbar) (R LPG G31-28-30mbar)	1
	1300401048	INJEKTOR 1.07mm TC4 LPG (G31-28-30mbar)	1
4	1300800001	TERMINAL BOX	1
5	1301500023	POWER CABLE	1
86	1301900012	WASHER KNURLED M4	2
87	1301900004	NUT M4	2
88	1301900003	CHEESE - HEAD SCREW M4X6 GALVANIC	2
75	1301500002	CABLE NOTR	1
76	1300001003	CABLE CLIP	2
6	1300800002	IGNITOR	1
15	1300800029	MICROSWITCH	1

20	1300100002	IGNITOR CLIPS	5
26	1300800006	THERMOCOUPLE 450mm	4
27	1300800008	THERMOCOUPLE 600mm WOK BURNER	1
28	1300800057	SPARK PLUG 600mm WOK BURNER	1
29	1300800005	SPARK PLUG 450mm	4
32	1300500005	WOK BURNER SEAL	1
33	1300601513	TOP PLATE	1
	1300401002	GRID FIXING PIN MODEL 2	6
	1300001001	ADHESIVE PENLOC GTH-T 50g	0.0333
34	1300501001	UNDER KNOB SEAL	5
35	1301301035	KNOB	5
36	1301100008	AUXILARY BURNER (FLAME SPREADER)	1
37	1301100006	SEMI-RAPID BURNER (FLAME SPREADER)	2
38	1301100007	RAPID BURNER (FLAME SPREADER)	1
39	1301100066	WOK BURNER (FLAME SPREADER)	1
40	1301100062	AUXILARY BURNER LID	1
41	1301100061	SEMI RAPID BURNER LID	2
42	1301100060	RAPID BURNER LID	1
43	1301100068	WOK BURNER LID (OUTER)	1
44	1301100067	WOK BURNER LID (INNER)	1
45	1301401184	PAN SUPPORT	1
46	1301401183	PAN SUPPORT	2
50	1300501109	FIXING PLASTIC	3
51	1300501111	SEAL	3
52	1300501103	SEAL WOK	1
54	1200301228	BURNER PLATE FOR RAPID BURNER	1
55	1200301196	BURNER PLATE FOR WOK BURNER	1
56	1200301227	BURNER PLATE FOR AUXILARY BURNER	1
57	1200301226	BURNER PLATE FOR SEMI-RAPID BURNER	2
81	1301900026	CHEESE - HEAD SCREW M3X12	8
83	1301900003	CHEESE - HEAD SCREW M4X6 GALVANIC	4
84	1301900022	WASHER M3x10 AL	8
90	1300501019	MAIN GAS PIPE STOPPER	1
77	1300800003	CABLE EARTHING	1
93	1300501108	FIXING PLASTIC	1
101	1300501110	SEAL	1