


# 110cm Black Cooker Hood

Model Number CHIM110BKPF

Parts Manual

# Exploded Drawing



02			
01			
00			
Index	Modify description	Modified by	Date

# Parts List

S/N	Ref.	Description	QTY	REMARK
1	B23-TD08-006-PX	TD INNER CHIMNEY BRACKET	1	
2	B21-TD08-008-TB2	TD INNER CHIMNEY-BLACK	1	
3	B23-TD08-005-PX	TD OUTER CHIMNEY BRACKET	1	
4	B21-TD08-007-TB2	TD OUTER CHIMNEY-BLACK	1	
5	B36-TT03-018-XG	Φ150 SMOKE TUBE	1	Optional
6	B67-TY04-005-XB	WIRE ONLY, WITHOUT PLUG	1	
7	B67-TY03-055-XX	SWITCH WIRE	1	
	B67-TY03-285-XX	SWITCH WIRE	1	
8	B67-TY03-022-XX	LIGHT WIRE	1	
9	B23-TG18-027-PX	WALL BRACKET	1	
10	B21-TD07-061-TB	FRONT DECORATIVE PLATE -BLACK	1	
11	B21-TD07-063-TB	REAR LAMPSHADE -BLACK	1	
12	B62-TY01-016-XX	LED LAMP	1	
13	B35-TD07-067-XX	5 LAYERS ALUMINIUM FILTER	3	
14	B60-TY05-005-XX	PUSH BUTTON- M02	1	
15	B30-TG18-015-JB	Φ150 VALVE	1	
16	B30-TI01-029-JB	HOUSING L -LEFT PART	1	
17	B30-TI01-028-JB	HOUSING L -RIGHT PART	1	
18	B61-TY02-002-XX	HOUSING L MOTOR	1	
19	B15-TF08-097-JB	CHARCOAL FILTER	2	Optional
20	B30-TT03-012-JB	FAN	1	
21	B30-TD08-020-JB	ELECTRIC CONTROL BOX	1	
	B30-TD08-021-JB	ELECTRIC CONTROL BOX	1	
22	B63-TY12-281-XX3	PCB	1	