


Visor Cooker Hood

Model Number VIS60SS

Parts Manual

Exploded Drawing



Parts List

S/N	Ref.	Description	QTY	REMARK
1	B67-TY04-005-XB	WIRE ONLY, WITHOUT PLUG	1	
2	B30-TF23-016-JB	FAN	1	
3	B30-TF23-012-JB	HOUSING A	1	
4	B62-TY01-210-XX	HALOGEN LIGHT	1	
5	B65-TY01-007-XX	E14 LAMP HOLDER	1	
6	B61-TY02-048-XX	MOTOR	1	
7	B34-TF20-038-XB	GREASE FILTER	1	
8	B30-TF16-029-JB	VALVE ASSEMBLY	1	
9	B30-TF08-027-JB	OUTLET COVER	1	
10	B76-TY05-005-BX2	PUSH BUTTON ASSEMBLY	1	
11	B67-TY03-019-XX	E14 LAMP WIRE	1	
12	B34-TF20-122-XB	CARBON FILTER	1	optional
13	B63-TY12-281-XX2	PCB	1	