


Gas Hob Model Number
CLGASUIT2

Parts Manual

Exploded Drawing



Parts List

Picture No	Component Number	Component Name	Amount
21	1200101065	BURNER BRIDGE	2
1	1200101775	BOTOM PLATE	1
9	1301000019	AUXILARY BURNER GAS VALVE	1
11	1301000021	RAPID BURNER GAS VALVE	1
14	1200101953	VALVE SHEET	1
22	1301100004	AUXILARY BURNER CUP	1
24	1301100003	RAPID BURNER CUP	1
82	1301900001	CHEESE - HEAD SCREW M4X15	4
85	1301900013	CHEESE - HEAD SCREW M3,5X6	4
13	1301201701	MAIN GAS PIPE	1
	1301201682	MAIN GAS PIPE SUPPORT PARTS	1
16	1301201662	GAS DISTRIBUTOR PIPE LEFT-FRONT BURNER	1
17	1301201663	GAS DISTRIBUTOR PIPE LEFT-REAR BURNER	1
80	1301900005	CHEESE - HEAD SCREW M3,9X9,5	11
7	1300401009	BENDS CONE	1
8	1301900011	GASKET KLINGRIK	1
89	1301900007	NUT M6X0,75	2
74	1200101029	TERMINAL BOX COVER	1
2	1300501029	LEAKPROOFING GASKET	1
3.1	1200101011	SHRINKING HOOK	4
3.2	1301900031	CHEESE - HEAD SCREW M4,2x40	4
108	1300401003	INJECTOR 0.50mm AUX LPG (G30-28-30mbar G31-37mbar)	1
107	1300401005	INJECTOR 0.85mm R LPG (G30-28-30mbar G31-37mbar)	1
4	1300800001	TERMINAL BOX	1
5	1301500023	POWER CABLE	1
86	1301900012	WASHER KNURLED M4	2
87	1301900004	NUT M4	2
88	1301900003	CHEESE - HEAD SCREW M4X6 GALVANIC	2
75	1301500002	CABLE NOTR	1
76	1300001003	CABLE CLIP	2
6	1300800013	IGNITOR	1
15	1300800014	MICROSWITCH	1
20	1300100002	IGNITOR CLIPS	2
26	1300800006	THERMOCOUPLE 450mm	2
29	1300800005	SPARK PLUG 450mm	2
33	1200101282	TOP PLATE	1
34	1300501011	UNDER KNOB SEAL	2
35	1301301005	KNOB	2
36	1301100008	AUXILARY BURNER (FLAME SPREADER)	1
38	1301100007	RAPID BURNER (FLAME SPREADER)	1
40	1301100062	AUXILARY BURNER LID	1
42	1301100060	RAPID BURNER LID	1
46	1301401029	PAN SUPPORT	1
81	1301900026	CHEESE - HEAD SCREW M3X12	4
90	1300501019	MAIN GAS PIPE STOPPER	1

