


Cooker Hood
Model Number UBADCH110SS
Parts Manual

Exploded Drawing



Parts List

S/N	Ref.	Description	QTY	REMARK
34	138B-SW	SCREW KIT	1	
33	1400500158	REMOTE CONTROL	1	
32	1300100452	AI FILTER	4	
31	150050101186-3	DECORATIVE PANEL	2	
30	1309800249	LEFT/ RIGHT HINGE	4	
29	1309800248	MAGNET RING	16	
28	12001010200141	TERMINAL BOX ANDCOVER	2	
27	1400600111	LED LAMP	4	
26	1130204353	LAMP PANEL	1	
25	1130204354	SWITCH PANEL	1	
24	1400500324	SWITCH	1	
23	120010300035	SWITCH BOX	1	
22	1130402310	SWITCH BRACKET	1	
21	1130204353	LAMP BRACKET	4	
20	1130204352	PANEL	1	
19	1130204357	SEAL RING ASSEMBLY	1	
18	12001010200064	PCB BOX COVER	1	
17	1400100052	CAPACITOR	1	
16	1400500275	PCB	1	
15	12001010200143	PCB BOX BOTTOM	1	
14	1120400092	PCB BOX BRACKET	1	
13	1130204351	BODY SHELF	1	
12	12001010300070	CARBON FILTER	2	Optional
11	12001010300019	RIGHT COVER OF PLASTIC BLOWER	1	
10	1400200353	MOTOR	1	
9	12001010300115	FAN	1	
8	12001010300018	LEFT COVER OF PLASTIC BLOWER	1	
7	1400400072	POWER CORD	1	
6	12001010300005	VALVE	2	
5	1130402045	MOTOR HOUSING	1	
4	1140300065	ADJUSTABLE FOOT ASSEMBLY	4	
3	1140400175	HANGING ANGLE	8	
2	1140300061	HANGING PLATE	2	
1	120010500008	PLASTIC PIPE	1	