


Ceiling Cooker Hood

Model Number UBADCH110W

Parts Manual

Exploded Drawing



| | | | |
|-------|--------------------|-------------|------|
| 02 | | | |
| 01 | | | |
| 00 | | | |
| Index | Modify description | Modified by | Date |

Parts List

| S/N | Ref. | Description | QTY | REMARK |
|-----|----------------|-------------------------------|-----|----------|
| 34 | 138B-SW | SCREW KIT | 1 | |
| 33 | 1400500158 | REMOTE CONTROL | 1 | |
| 32 | 1300100452 | AI FILTER | 4 | |
| 31 | 150050101186-2 | DECORATIVE PANEL | 2 | |
| 30 | 1309800249 | LEFT / RIGHT HINGE | 4 | |
| 29 | 1309800248 | MAGNET RING | 16 | |
| 28 | 12001010200141 | TERMINAL BOX AND COVER | 2 | |
| 27 | 1400600111 | LED LAMP | 4 | |
| 26 | 1130204353 | LAMP PANEL | 1 | |
| 25 | 1130204354 | SWITCH PANEL | 1 | |
| 24 | 1400500324 | SWITCH | 1 | |
| 23 | 120010300035 | SWITCH BOX | 1 | |
| 22 | 1130402310 | SWITCH BRACKET | 1 | |
| 21 | 1130204353 | LAMP BRACKET | 4 | |
| 20 | 1130204352 | PANEL | 1 | |
| 19 | 1130204357 | SEAL RING ASSEMBLY | 1 | |
| 18 | 12001010200064 | PCB BOX COVER | 1 | |
| 17 | 1400100052 | CAPACITOR | 1 | |
| 16 | 1400500275 | PCB COVER | 1 | |
| 15 | 12001010200143 | PCB BOX BOTTOM | 1 | |
| 14 | 1120400092 | PCB BOX BRACKET | 1 | |
| 13 | 1130204351 | BODY SHELF | 1 | |
| 12 | 12001010300070 | CARBON FILTER | 2 | Optional |
| 11 | 12001010300019 | RIGHT COVER OF PLASTIC BLOWER | 1 | |
| 10 | 1400200353 | MOTOR | 1 | |
| 9 | 12001010300115 | FAN | 1 | |
| 8 | 12001010300018 | LEFT COVER OF PLASTIC BLOWER | 1 | |
| 7 | 1400400072 | POWER CORD | 1 | |
| 6 | 12001010300005 | VALVE | 2 | |
| 5 | 1130402045 | MOTOR HOUSING | 1 | |
| 4 | 1140300065 | ADJUSTABLE FOOT ASSEMBLY | 4 | |
| 3 | 1140400175 | HANGING ANGLE | 8 | |
| 2 | 1140300061 | HANGING PLATE | 2 | |
| 1 | 120010500008 | PLASTIC PIPE | 1 | |