


Cooker Hood
Model Number UBICON75W
Parts Manual

Exploded Drawing



Parts List

S/N	Ref.	Description	QTY	REMARK
1	1400400072	POWER CORD	1	
2	12001010300005	VALVE	2	
3	UBICON75W CAVITY ASS	CAVITY ASSEMBLY	1	
4	1120400092	JUNCTION BOX BRACKET	1	
5	12001010200143	JUNCTION BOX BOTTOM	1	
6	1400500180	PCB BOARD	1	
7	1400100077	CAPACITOR	1	
8	12001010200017	JUNCTION BOX COVER	1	
9	12001010300019	RIGHT VOLUTE	1	
10	1400200249	MOTOR	1	
11	12001010300011	IMPELLER	1	
12	12001010300018	LEFT VOLUTE	1	
13	12001010300070	CARBON FILTER	2	Optional
14	1170300444	FRAME	1	
15	UBICON75W BUCKLE ASS	BUCKLE ASSEMBLY	4	
16	1309800167	MAGNET	2	
16	1309800166	COUNTERSUNK SCREW	8	
17	1120200353	LEFT HINGE	1	
18	1120200354	RIGHT HINGE	1	
19	1130203191	FRONT PLATE CONNECTOR	2	
20	1170300451	BACKBOARD	1	
21	1170300453	HEAD BOARD	1	
22	1120400216	LAMP BRACKET	2	
23	1400600300	LED LIGHT	2	
24	120010300066	SWITCH BOX COVER	1	
25	1400500130	SWITCH PLATE	1	
26	UBICON75W OUTER GLASS ASS	OUTER GLASS ASSEMBLY	1	
27	1300100466	ALUMINIUM FILTER	1	
28	UBICON75W INNER GLASS ASS	INNER GLASS ASSEMBLY	1	
29	UBICON75W SB	SCREW BAG	1	