




Dishwasher:DW45M

Version:00

Date:2015-04-03


Product reference code:DW45M

# DW45M Exploded drawing(1)




00	New document	Eason	2015. 4. 3
Index	Modify description	Modified by	Date

# DW45M Exploded drawing(2)



## DW45M Exploded drawing(3)



# DW45M parts list

No.	Factory Code	Part Description	Qty
1001	673000900223	External pipe	1
1002	673001500005	O Ring I 31.5X3.55	2
1003	673001800364	Guide casing	1
1004	673001600021	External pipe nut	1
1005	673001900038	Water dispenser	1
1006	673000300077	Upper sprayer	1
1007	673000900195	Upper sprayer pipe	1
1010	673001490016	Float support	1
1011	672000900012	Screw ST2.9x22	1
1012	673002300003	Float	1
1013	674000300060	Micro switch	1
1016	673002500072	Micro filter	1
1017	673001600022	Sump nut	1
1018	673001500122	Sump gasket	1
1019	673000701037	Sump	1
1020	672000700028	Clamp 12.7×1.8	2
1022	673000900160	PVC hose	1
1027	674000600106	drain pump	1
1029	673002200043	Salt filler	1
1030	673002800050	Softener cover assembly	1
1031	673001700053	Softener cover gasket	1
1032	673001600039	Softener nut	1
1033	673001700001	Softener gasket	1
1034	670400051196	Softener	1
1035	673000900219	Flexible hose	1
1036	672000700029	Clamp 14.5×1.8	5
1037	673006200027	Drain hose hook	1
1038	673001500002	Drain hose holder	1
1039	673000900251	Drain hose	1
1042	674000000194	Power cord	1
1043	674000200002	inlet valve	1
1045	673000900205	Inlet hose assembly	1
1046	673000900026	Regeneration hose	1
1047	673000900224	Outlet hose of air breather	1
1048	673000900237	Inlet hose of air breather	1
1051	673001600025	Ring nut air breather	2
1054	673002700008	Air breather assembly	1
1064	670400051618	Lower sprayer	1
1070	670400061725	Washing pump	1
1083	673000900045	Bend connect hose	1
1085	673001400025	Heating element support	1
1086	674001100044	Heating elements	1
1088	673001600024	Water inlet nut	1
1089	673001500019	Water inlet gasket	1
1091	670400054000	Water inlet	1
1093	674000900053	Sensing device	1
1113	672000600021	plane filter	1
1114	673001300179	Scran collection	1
1115	670400051262	pressure switch(140/120)	1
1116	673001400083	power cord clasper	1
1117	674000302006	pressure switch for heater	1
2001	673002000098	Door edge guard piece	2
2002	672002200381	Inner door assembly	1
2004	672001700002	Dispenser bracket	2
2005	674000800058	Dispenser	1
2006	674000101006	Wiring assembly	1

2007	675000200104	Inner door foam	1
2008	672000500006	Ring Φ6	4
2009	672001300029	Left hinge	1
2010	672001200012	Joint pin	2
2011	672001300030	Right hinge	1
2012	672001300023	Door gemel assembly	1
2013	672000100030	Door spring	2
2014	672001100001	Door spring bolt	2
2017	672001800843	Outer door	1
2018	673000456530	Control panel	1
2019	673000801123	Knob	1
2023	673001800687	Handle assembly	1
2027	674000300065	Power switch	1
2033	673000900162	Red pilot lamp	10
2034	674001001498	Control board	1
2036	673002400190	Control board box	1
2950	673000890333	Power button	1
2952	673000802859	Temperature button	1
3001	672001600239	Left panel	1
3003	672002190013	Left uprights	1
3004	673000200232	Ceiling board	1
3005	673003100016	Upper rear crosspiece	1
3008	673001300003	Top board hook	2
3009	672001500151	Upper front crosspiece	1
3010	673001700078	Tank gasket	1
3011	672002190014	Right uprights	1
3012	672001600240	Right panel	1
3013	673001300102	Cup rack	4
3017	672000803070	Lower basket	1
3018	670400071211	Upper basket	1
3019	675000200101	Sound-proof felt	1
3020	673001100148	Right side baseboard	1
3021	673001300181	Guide rail block	4
3022	672001701000	Guide rail	2
3023	673001401025	Rail support assembly	4
3024	673001100170	Baseboard	1
3025	673001100180	Adjustable foot	4
3026	672000200004	Foot rest	2
3027	670400050130	Lower front crosspiece	1
3029	670400050027	Tray assembly	1
3030	673001100147	left side baseboard	1
3031	672001902438	Tank assembly	1
3032	673001700010	Tank band bracing block	2
3033	672001500200	Lower rear crosspiece	1
3034	672001500114	Middle rear crosspiece	1
3035	673002200079	Ration spoon	1
1071+1072	672000200054	Washing motor support	1
1074-a	673000900228	Connect hose a	1
1074-b	673000900229	Connect hose b	1
3006+3007	673001300170	Door lock and clamp	1
3014+3015+3016	670400055019	Cutlery basket assembly	1
C5004	673006200004	rinsing agent cup	1
OTK 175	672000700004	OTK 175	4
OTK 286	672000700003	OTK 286	1
OTK 310	672000700001	OTK 310	7
OTK 396	672000700007	OTK 396	2
OTK 286	672000700003	OTK 286	1