



Washing Machine:WDH60

Version:03

Date:2016-06-07

Product reference code:WDH60

This exploded view diagram illustrates the assembly of a washing machine. The components are numbered 1 through 106. A red line traces the assembly path from the door (1) and its handle (11) through the door frame (2, 3, 4, 5), the main body (6, 7, 8), the drum (9, 10), and the motor (93) to the final assembly (106). The diagram also shows the control panel (14) and the top panel (26) being attached to the main body. The motor (93) is shown with its drive belt (94) and pulley (95). The drum (9) is shown with its internal baffles (96, 97, 98, 99) and the motor (93) is shown with its drive belt (94) and pulley (95). The diagram also shows the control panel (14) and the top panel (26) being attached to the main body. The motor (93) is shown with its drive belt (94) and pulley (95). The drum (9) is shown with its internal baffles (96, 97, 98, 99) and the motor (93) is shown with its drive belt (94) and pulley (95).

WDH60 parts list

| No. | Ref code | supplier code | description | Qty |
|-----|----------|-----------------|--|-----|
| 1 | 69406995 | 0020203677 | front frame of the porthole-washing machine-WDH60 | 1 |
| 2 | 69407000 | 00214800591000 | handle of the porthole-washing machine-WDH60 | 1 |
| 3 | 69407005 | 0020102695 | hook of the porthole-washing machine-WDH60 | 1 |
| 4 | 63700510 | 00221120012000 | shaft of the hook-washing machine-WDH60 | 1 |
| 5 | 63300090 | 00221122324008 | spring of the hook-washing machine-WDH60 | 1 |
| 6 | 69407010 | 0021400011A | glass of the porthole -washing machine-WDH60 | 1 |
| 7 | 69407015 | 0020203678 | inner frame of the porthole-washing machine-WDH60 | 1 |
| 8 | 69407020 | 0020203680 | door hook protection-washing machine-WDH60 | 1 |
| 9 | 60702005 | 00214800021100 | nylon nut-washing machine-WDH60 | 1 |
| 10 | 69407025 | 00221122312010 | gemel-washing machine-WDH60 | 2 |
| 11 | 69407030 | 0020202224A | handle of the detergent tray-washing machine-WDH60 | 1 |
| 12 | 69407035 | 0020200448 | detergent tray-washing machine-WDH60 | 1 |
| 13 | 63700515 | 00213600039700 | shaft of the handle-washing machine-WDH60 | 1 |
| 14 | 69407040 | 0020200139C | control panel-washing machine-WDH60 | 1 |
| 15 | 60702010 | 0020203674 | program knob-washing machine-WDH60 | 1 |
| 16 | 69407045 | 0020203675 | connection shaft-washing machine-WDH60 | 1 |
| 17 | 69407050 | 0024000143 | electronic board-washing machine-WDH60 | 1 |
| 18 | 69407055 | 0020201502 | cover of the electronic board-washing machine-WDH60 | 1 |
| 19 | 69407060 | 00214800909100 | clip A-washing machine-WDH60 | 1 |
| 20 | 60100300 | 0020400102 | wiring assembly -washing machine-WDH60 | 1 |
| 21 | 69407065 | 0020400505E | door lock-washing machine-WDH60 | 1 |
| 22 | 69407070 | 0024000158 | 1-level pressure switch-washing machine-WDH60 | 1 |
| 23 | 69407075 | 00221120372006 | clip of wire line-washing machine-WDH60 | 1 |
| 24 | 69407080 | 0020400491 | anti-jamming filter-washing machine-WDH60 | 1 |
| 25 | 69407085 | 00221120022006 | panel of the anti-jamming filter-washing machine-WDH60 | 1 |
| 26 | 25103910 | 0020103071 | top panel-washing machine-WDH60 | 1 |
| 27 | 25103915 | 0024000211 | valve(single valve)-washing machine-WDH60 | 1 |
| 28 | 69407090 | 00211320015200A | clip B-washing machine-WDH60 | 2 |
| 29 | 25103920 | 00216000688700A | valve(dual valve)-washing machine-WDH60 | 1 |
| 30 | 25103925 | 0020201728 | storage tank assembly-washing machine-WDH60 | 1 |
| 31 | 69407095 | 0024000048 | driver board -washing machine-WDH60 | 1 |
| 32 | 60100305 | 0020400185 | power cable-washing machine-WDH60 | 1 |
| 33 | 69407100 | 00215200018100 | support of cable line and drain hose-washing machine-WDH60 | 3 |
| 34 | 60500370 | 0020300012B | packing rubber washer-washing machine-WDH60 | 3 |
| 35 | 69407105 | 0020300423 | packing rubber hose-washing machine-WDH60 | 3 |
| 36 | 69407110 | 00215200015200 | support of cable line -washing machine-WDH60 | 3 |
| 37 | 69407115 | 00214800909100 | clip C-washing machine-WDH60 | 1 |
| 38 | 25103930 | 00221103330712A | back cover-washing machine-WDH60 | 1 |
| 39 | 69407120 | 00221120021000 | clip D-washing machine-WDH60 | 1 |
| 40 | 25103935 | 0020103125 | cabinet assembly (white)-washing machine-WDH60 | 1 |
| 41 | 63500150 | 00221152310002A | nut of the adjustable foot-washing machine-WDH60 | 4 |
| 42 | 69407125 | 0020300170 | adjustable foot-washing machine-WDH60 | 4 |

WDH60 parts list

| No. | Ref code | supplier code | description | Qty |
|-----|----------|-----------------|---|-----|
| 43 | 69407130 | 0020600062 | Front tightening ring of cushion of sight window-washing machine-WDH60 | 1 |
| 44 | 69407135 | 0020300146A | Cushion of sight window-washing machine-WDH60 | 1 |
| 45 | 69407140 | 0020600063 | Back tightening ring of cushion of sight window-washing machine-WDH60 | 1 |
| 46 | 69407145 | 0020102828A | Drying motor cover-washing machine-WDH60 | 1 |
| 47 | 69407150 | 00214400095300 | Sealing bar of drying device-washing machine-WDH60 | 1 |
| 48 | 69407155 | 00213400022400 | Lower baffle board-washing machine-WDH60 | 1 |
| 49 | 69407160 | 00216000749601 | Dry heating element-washing machine-WDH60 | 1 |
| 50 | 69407165 | 00213400022302 | Baffle board-washing machine-WDH60 | 1 |
| 51 | 69407170 | 00214000002016 | Drying motor lower cover-washing machine-WDH60 | 1 |
| 52 | 69407175 | 00216000019802 | Thermostat-washing machine-WDH60 | 1 |
| 53 | 64900795 | 0024000237 | Drying motor-washing machine-WDH60 | 1 |
| 54 | 62901780 | 00215200000900 | Tightening spring clip of drier device-washing machine-WDH60 | 4 |
| 55 | 69407180 | 00217400001301 | Unilateralism blower fan-washing machine-WDH60 | 1 |
| 56 | 69407185 | 00214400004604 | Sponge gasket for drier-washing machine-WDH60 | 1 |
| 57 | 69407190 | 00214800038700 | Clip E-washing machine-WDH60 | 1 |
| 58 | 69407195 | 0020103005B | Front flange of outer cylinder-washing machine-WDH60 | 1 |
| 59 | 69407200 | 0020300113 | Front flange of outer cylinder seal-washing machine-WDH60 | 1 |
| 60 | 63500155 | 00217690020008A | Square nut-washing machine-WDH60 | 1 |
| 61 | 25103940 | 0020803254 | inner cylinder assembly-washing machine-WDH60 | 1 |
| 62 | 69407205 | 0020300391 | Sealing cushion of condenser-washing machine-WDH60 | 1 |
| 63 | 69407210 | 0020802789A | Current adjuster assembly-washing machine-WDH60 | 1 |
| 64 | 69407215 | 00215200799802A | Current adjuster clip-washing machine-WDH60 | 1 |
| 65 | 69407220 | 00214400008504 | Isolated bushing-washing machine-WDH60 | 1 |
| 66 | 69407225 | 00214400008402 | Hose connecting electromagnetism valve to condenser-washing machine-WDH60 | 1 |
| 67 | 69407230 | 0020202736 | Condenser -washing machine-WDH60 | 1 |
| 68 | 69407235 | 00215200799802A | Condenser hose clip-washing machine-WDH60 | 1 |
| 69 | 69407240 | 0020300491 | Condenser hose-washing machine-WDH60 | 1 |
| 70 | 69407245 | 00200017445000 | Triangle of inner cylinder-washing machine-WDH60 | 1 |
| 71 | 69407250 | 0020805176 | Outer cylinder assembly-washing machine-WDH60 | 1 |
| 72 | 69407255 | 00221124038000 | Sealing cushion-washing machine-WDH60 | 3 |
| 73 | 62700425 | 00215200040610A | Stretching spring-washing machine-WDH60 | 2 |
| 74 | 69407260 | 00214800503000 | Bracket sheath for spring-washing machine-WDH60 | 4 |
| 75 | 69407265 | 00218230460611A | Clip F-washing machine-WDH60 | 1 |
| 76 | 69407270 | 00214400520502 | Hose connecting cylinder to dispenser -washing machine-WDH60 | 1 |
| 77 | 69407275 | 00214400053800 | Oil seal-washing machine-WDH60 | 1 |
| 78 | 63700520 | 0020102392 | Ball bearing-washing machine-WDH60 | 1 |
| 79 | 69407280 | 0020102778 | Triangle of outer cylinder-washing machine-WDH60 | 1 |
| 80 | 69407285 | 0020102393 | Ball bearing-washing machine-WDH60 | 1 |
| 81 | 69407290 | 0020102869 | Pulley-washing machine-WDH60 | 1 |
| 82 | 69407295 | 0020300283 | Belt-washing machine-WDH60 | 1 |
| 83 | 61900170 | 00215000014200A | Washer-washing machine-WDH60 | 1 |
| 84 | 62700430 | 00291200000100A | Screw for pulley -washing machine-WDH60 | 1 |
| 85 | 69407300 | 0020300289 | seal-washing machine-WDH60 | 1 |
| 86 | 69407305 | 0020804120A | Shock absorber-washing machine-WDH60 | 2 |
| 87 | 61900175 | 00217440540612 | Buffer gasket-washing machine-WDH60 | 3 |
| 88 | 62700435 | 00215000015902A | Screw of motor-washing machine-WDH60 | 1 |
| 89 | 64900800 | 0024000084 | Motor-washing machine-WDH60 | 1 |
| 90 | 69407310 | 00211500013900 | Motor long bushing-washing machine-WDH60 | 1 |
| 91 | 69407315 | 00214400042900 | Motor bush-washing machine-WDH60 | 3 |
| 92 | 63500160 | 00215000012500A | Nut-washing machine-WDH60 | 2 |
| 93 | 69407320 | 00211500013900 | Motor long bushing-washing machine-WDH60 | 1 |
| 94 | 69407325 | 00216000695901 | Water heating element-washing machine-WDH60 | 1 |
| 95 | 69407330 | 0020102634 | racket of heating element-washing machine-WDH60 | 1 |
| 96 | 69407335 | 00215200038602A | Clip of hose connecting cylinder to pump-washing machine-WDH60 | 1 |
| 97 | 69407340 | 00211320011300A | Clip G-washing machine-WDH60 | 1 |
| 98 | 69407345 | 00217400046900 | Air trap -washing machine-WDH60 | 1 |
| 99 | 62700440 | 00215000008800A | Screw-washing machine-WDH60 | 1 |
| 100 | 69407350 | 00211320015200A | Clip H-washing machine-WDH60 | 1 |
| 101 | 69407355 | 00214401362902 | Pressure switch hose-washing machine-WDH60 | 1 |
| 102 | 69407360 | 00212500011100 | Sponge-washing machine-WDH60 | 3 |
| 103 | 69407365 | 00218210650611A | Clip I-washing machine-WDH60 | 1 |
| 104 | 69407370 | 00221120363014 | Clip J-washing machine-WDH60 | 1 |
| 105 | 69407375 | 0020600050A | Clip K-washing machine-WDH60 | 1 |
| 106 | 69407380 | 0020300148 | Drain pipe-washing machine-WDH60 | 1 |
| 107 | 69407385 | 0020400647 | Drain pump-washing machine-WDH60 | 1 |
| 108 | 69407390 | 00215200294400A | Clip L-washing machine-WDH60 | 1 |
| 109 | 69407395 | 0020300010 | Pump hose-washing machine-WDH60 | 1 |
| 110 | 69407400 | 0020102738A | front counterweight-washing machine-WDH60 | 1 |
| 111 | | 0020103078A | hinge | 2 |
| 112 | | 0020803673 | magnet assembly | 2 |