




Gas Oven:UBGMM60SS

Version:01

Date:2015-04-30

Product reference code: UBGMM60SS

UBGMM60SS Exploded drawing



01	Revise No. 20&64	Eason	2015. 4. 30
00	New document	Eason	2014. 10. 7
Index	Modify description	Modified by	Date

UBGMM60SS parts list

No.	part code	part name	Qty	Remark
1	33313002	cooling fan assembly	1	
2	32304002	3200 impulse ignition device	1	
3	33035001	thermostat switch sensor clip	2	
4	33229002	The upper temperature adjust connecting pipe	1	
5	33030003	back cover	1	
6	33305002	power cord connector	1	
7	33304078	power cord	1	
8	33120002	heat preservation fibre-white	1	
9	33016001	back bracket	1	
10	33302002	lamp assembly	1	
11	32160028	intake tube(k4-40)	1	
12	33319001	heat preservation fibre spring	3	
13	33229001	The lower temperature adjust connecting pipe	1	
14	33120002	inner bladder- guide rail formed in one piece	1	
15	33049001	heat preservation fibre-white	1	
16	33018105	intake tube fixer	1	
17	33058073	door frame	1	
18	33025003	Right bracket	1	
19	33005004	hinge fixer	2	
20	32312036	thermocouple(k4-14)	1	From 2015.03.20 to stop using
	32312019	thermocouple		From 2015.03.20 to start using
21	32300017	ignition pin	2	
22	33227001	nozzle fixer	2	
23	33228001	ignition pin fixier	4	
24	32192028	nozzle	1	
	33192038		1	
25	33803001	door sealing assembly	1	
26	33804001	burning pipe assembly	1	
27	33046001	burner fixing board	1	
28	33029009	lower cover	1	
29	33224003	tray	1	
30	33048001	burner guard board	1	
31	33180016	hinge assembly	2	
32	33010034	doorframe subassembly	1	
33	33103006	inner glass(k1-20-06)	1	
34	33036008	middle glass fixer	2	
35	33104030	middle glass(k4-32)	1	
36	33014001	panel bottom fixing bracket	2	
37	33015226	switch board decorative board	1	
38	33102454	door glass panel	1	
39	33190004	handle	1	
40	33006012	handle fixing board	2	
41	33170001	shelf	1	
42	33170003	shelf in tray	1	
43	33172001	rack handle	1	
44	32245003	knob	3	
45	33007110	control panel decorative board	1	
46	33101419	control panel	1	
47	91034002	single adhesive tape	1	
48	33006001	switch board connecting board	4	
49	32244078	knob washer	3	
50	33307002	timer switch	1	
51	33301014	function swtch	1	
52	33312002	pilot lamp	1	
53	33232002	temperature switch	1	
54	33033002	left oven casing	1	
55	33032002	right oven casing	1	
56	33214001	inner bladder board washer	2	
57	33804007	The upper burning pipe assembly	1	
58	33024003	Left bracket	1	
59	33027001	exhausting pipe cover board	1	
60	32192084	NG nozzle	1	
	32192069	LPG nozzle	1	
61	33215004	exhausting pipe bottom panel	1	
62	33215003	exhausting pipe top panel	1	
63	33310001	65℃ cooling fan thermostat	1	
64	32312024	thermocouple(k10-04)	1	From 2015.03.20 to stop using
	32312054	thermocouple		From 2015.03.20 to start using
65	33026006	cooling fan top cover	1	
66	33308014	150℃ cut-out thermostat	2	
67	33031001	top cover	1	
68	33313007	cooling fan cover	1	