





Oven:UBAPY60SS

Version:00

Date:2015-01-06

Product reference code: UBAPY60SS

UBAPY60SS Exploded drawing



00	New document	Eason	2015. 01. 06
Index	Modify description	Modified by	Date

UBAPY60SS parts list

No.	Part Code	Part name	Qty
A23	261500616701	front plate	1
A35	262101400122	cavity sealing ring	1
A49	291500100011	encloser assembly (Right)	1
A50	291500100010	encloser assembly (Left)	1
A69	261564100800	ventilation cover inlet	1
C05	261517208400	power cord bracket	1
C13	261561900400	control panel back cover	1
C16	261561800600	control panel cover	1
G07	261201002601	power cord	1
G09	261257100050	terminal block	1
G14	261200300160	door lock	1
G16	291201300011	cooling fan motor	1
G21	261201301110	thermostat	2
H02	291400200007	power board	1
I01	291599900023	fastener assembly	1
I09	291503400002	Following encloser assembly	1
I29	261561600400	back cover	1
I41	261302201200	exhaust seat	1
I46	291503400001	top cover assembly	1
I48	261331200201	handle box	2
I63	261504501200	hinge fixed frame (Right)	1
I64	261504501100	hinge fixed frame (Left)	1
A00	\	cavity ass'y	
A12	291501300035	bake rack	1
A12-1	291501300046	bake tray rack	1
A15	291501400002	bake tray (deep)	1
A30	291504600257	cavity	1
A32	262100600072x1 262100600073x1	Cavity insulation	1
A42	291503400004	convection motor cover	1
A43	261508200600	convection fan blade	1
A53	291200800039	under heating element cover	1
A61	291200800035	metal heating element*(top)	1
A62	261201702190	turbo heating element	1
G10	261257700038	lamp	1
G18	291201300015	convection motor	1
G20	263004100027	temperature sensor	1
I19	261564600300	insulation cover	1
I26	292100200020	back insulation	1
I40	261564400300	exhaust pipe	1

B00	291506103209	door ass'y	1
B01	262100800105	door handle cushion	2
B02	291300600021	handle support	2
B06	291501700003	door decoration	1
B11	261566702300	door hinge ass'y	2
B12	261509400902	door handle	1
B13	262155000038	door inner glass	1
B16	291502300037	door frame ass'y	1
B19	262155500014	Door sealing ring	2
B23	291599900021	door frame bracket	2
B25	291599900020	door frame bracket(Left)	2
B26	291800800001	door outer glass	1
B28-1	262155100011	door middle glass A	1
B28-2	262155000039	door middle glass B	1
B32	292100800019	upper glass bracket	2
B33	262100800182	lower glass bracket	2
B34	291399900026	door lock latch	1
B35	291399900009	door lock holder	1
B36	262101400121	Door sealing gasket	1
C00	291506103208	control panel ass'y	1
C01	291300100007	button	4
C02	261358201900	button bracket	2
C03	261312501700	button skirt	4
C11	261561001709	control panel holder	1
C12	292100300002	control panel sponge	2
C14	292100400001	film of control panel	1
C15	291501700003	control panel decoration	2
C17	261563800900	control panel bracket	2
C20	292100500234	control panel glass	1
C26	261313002600	display bracket	1
C29	261312505500	skirt cramp	4
C30	291301000068	Knob Assembly	2
H01	291400100034	display board	1