


60cm Black Angled Glass Cooker Hood

Model Number AG60PF

Parts Manual

Exploded Drawing



02			
01			
00			
Index	Modify description	Modified by	Date

Parts List

S/N	Ref.	Description	QTY	REMARK
1	B23-TD08-006-PX	Upper chimney bracket	1	
2	B21-TD08-008-TB2	Upper chimney	1	
3	B23-TD08-005-PX	Lower chimney bracket	1	
4	B21-TD08-007-TB2	Lower chimney	1	
5	B23-TG18-027-PX	Wall bracket	1	
6	B30-TD08-020-JB	Electric control box -lower part	1	
7	B63-TY12-281-XX3	PCB board	1	
8	B63-TY07-011-XX1	LED drive power box	1	
9	B30-TD08-021-JB	Electric control box -upper part	1	
10	B21-TV26-014-TB	Glass fix holder-left	1	
	B21-TV26-015-TB	Glass fix holder-right	1	
11	B21-TV13-005-TB	Lampshade	1	
12	B62-TY01-016-XX	LED lamp	2	
13	B33-TV26-001-XB	Flexible (outer) glass	1	
14	B21-TV27-002-XB	Glass fixed holder-left	1	
	B21-TV27-003-XB	Glass fixed holder-right	1	
15	B35-TG01-018-XX	5 layers Aluminium Filter	1	
16	B30-TD02-027-JB	Housing S -right part	1	
17	B61-TY02-017-XX	Housing S motor	1	
18	B15-TD02-024-JB	Charcoal filter	2	Optional
19	B30-TD02-016-JB	Fan	1	
20	B30-TD02-026-JB	Housing S -left part	1	
21	B60-TY05-009-XX	Push button- M03	1	
22	B67-TY03-055-XX	Switch wire-section A	1	
23	B67-TY03-046-XX	Switch wire-section B	1	
24	B67-TY03-024-XX	Light wire	1	
25	B67-TY04-005-XB	Wire only, without plug	1	