


Downdraft Cooker Hood
Model Number UBDDCHC60A
Parts Manual

Exploded Drawing



Parts List

ID No	Part Number	Description	QTY	REMARK
40	128A-BANN	Screw kit	1	
39	1400400072	Power cord	1	
38	1139801907	PCB bottom cover	1	
37	12001010 200143	PCB bottom	1	
36	1400500264	PCB	1	Use to 17W42
	1400500319	PCB	1	Use from 17W43
35	1400100005	Capacitor	1	
34	1200101020 0064	PCB cover	1	
33	1130401144	PCB outter cover	1	
32	1130401147	Motor housing	1	Use to 17W42
	1130402012	Motor housing	1	Use from 17W43
31	1400200166	Motor accessory	2	
30	12001010 300005	Valve	1	
29	12001 0500008	Plastic Pipe	1	
28	1130201682	Spindle bottom fixed bracket	1	
27	1400200245	Spindle	1	
26	1309800156	Guide rail	4	
25	1130401143	Spindle filler	2	
24	1309900056	Drag chain	1	
23	1140400182	Fixed feet	2	
22	60cm:1139801905 90cm:1139801906	Body cover	1	Use to 17W42
	60cm:1139802979 90cm:1139802977	Body cover	1	Use from 17W43
21	1130401150	Body back cover	1	
20	1309900049	Spring guide shaft	60cm :1 90cm :2	
19	1300500024	Spring	60cm :1 90cm :2	
18	60cm: 128A-HA60 90cm:128A-HA90	Housing assembly	1	
17	60cm:1130401139 90cm:1130401141	Connected board	2	
16	60cm:1130201694 90cm:1130201701	Panel	1	
15	60cm:1139801680 90cm:1139801682	Decorative panel	1	
14	1309800227	Carbon filter mat fixed wire	60cm :3 90cm :4	
13	60cm:1309800194 90cm:1309800193	Carbon filter mat	1	
12	60cm :1300100143 90cm :1300100144	Aluminum filter	1	

11	60cm :1130201689 90cm :1130201696	Lamp panel	1	
10	1400600060	LED light	2	
9	1130201684	Micro switch pressure panel	1	
8	1130201685	Micro switch bracket	1	
7	1130203525	Micro switch fix panel	1	
6	1400300001	Micro switch	2	
5	1130201680	Spindle cover	1	
4	60cm :1139801679 90cm :1139801681	Shell enhance strip	1	
3	120010 300067	Switch box cover	1	
2	1400500116	Switch board	1	Use to 17W42
	1400500320			Use from 17W43
1	60cm:150050100097; 90cm:150050100099	Glass switch panel	1	